




# **Installation Instructions**

Congratulations on your purchase of the ReFlex-rotating mailbox bracket.

Before you begin, please refer to the parts list to ensure all materials needed for assembly have been received.

Parts Included with this Product		
<u>Item</u>	Quantity	<u>Description</u>
A.	1	ReFlex-rotating metal bracket
В.	1	Wood Platform
C.	4	ReFlex Attachement Screws 2.5"
D.	1	#2 Square Bit
E.	4	Mailbox - Side Attachment Screws 1.25"
F.	4	Mailbox - Side Attachment Screws 2.25"
G.	4	Mailbox - Spacers (Optional)
н.	4	Mailbox - Internal Attachment Screws .75"



#### **Tools Required**

- Tape measure
- Power Screwdriver and Phillips Bit
- Pencil

### Read each step thoroughly prior to installing:

#### Determine mounting option

- 1. Horizontal Mount
- 2. Post Mount

## 1. Horizontal Mount

**Step 1** - Confirm required gap between back of mailbox and vertical post for rotation. See minimum gap reference.

**Step 2** - Secure ReFlex using Part C quantity 4 screws with Part D #2 Square screwdriver bit and Power Screwdriver.

**Step 3** - Position round cutout on Part B over fulcrum on Part A.

Step 4 - Mailbox Attachment

- Side Mount Mailbox (Preferred Method)
- Standard 6" T1 Mailbox: Position mailbox side mounting holes with oblong openings on Part A. Secure mailbox using Part E quantity 4 screws into Part B.




- Oversized 8"+ T2/T3 Mailbox: Position mailbox side mounting holes with oblong openings on Part A. Using Part G quantity 4 spacers between Part A and mailbox bottom side lip, secure mailbox using Part F quantity 4 screws into Part B. \*Spacer gap will vary depending on mailbox width.
- Internal Mount Mailbox
  - Secure Part B to Part A through oblong opening and into wood using Part E quantity 4 screws. Center mailbox over mailbox platform and attach with Part H quantity 4 Panhead screws.

#### 2. Post Mount

**Step 1** - Center 4x4 Mounting Base Plate over wooden post, aligning corners.

⇒Go To Step 2 above to complete installation as the process is the same.



6" T1 Mailbox = 1" Minimum

8" T2 Mailbox = 1.5" Minimum

Step 1

Step 2