


## **INSTALLATION INSTRUCTIONS**

**Package Contains:** Tub Spout **#191-S**  
Gooseneck Riser Pipe **#199-R**  
Wall Support Bracket w/ Screws **#4195-WS**  
Shower Head **#1003**

### **Tools Needed**

- Phillips Screwdriver • Level • 1/4" Drill Bit •
- Wrench • Wood Screws • Set Screw •



1. Before beginning any work be sure to shut off the water supply.
2. Apply teflon tape to ends of both the hot and cold supply nipples.  
Place valve body through holes in tub. Thread the large locknuts onto the other ends of the nipples and secure the shower set to the tub.
3. Assemble shower head to gooseneck riser pipe.
4. Slip the wall bracket over the straight end of the riser pipe. Carefully slide the bracket to the appropriate position (approximately half-way up the rod) and tighten the set screw provided.
5. Assemble riser pipe to the riser coupling assembly on the spout by tightening the coupling nut. After hand tightening, fasten securely by using a wrench.
6. Secure wall support bracket to the wall using the wood screws provided.
7. Turn on water supply.