

Pop-Up Projection Alarm Clock




Model: 616-1950
DC:122817

POWER UP

1. Insert the 5.0 volt power cord into an outlet, then into your clock. Optional: Install 2-AAA batteries into the bottom of your clock.

BUTTONS



SETTINGS

- Hold the SET button to enter time set mode.
- Press the + or - button to adjust the values.
- Press the SET button to confirm adjustments and move to the next item.
- Press the SNOOZE/LIGHT button at any time to exit.

Settings order:

Language: English | Spanish

Beep: ON | OFF

Hour

Minutes

Year

Month

Date

Fahrenheit | Celsius

Snooze Duration: 5 to 120 minutes

Note: Weekday adjusts automatically when year, month, and date are set.

OTHER BUTTON FUNCTIONS

Set Alarm

- Hold for 2 seconds to enter alarm set mode
- Press +/- to adjust values and to confirm
- Press to activate or deactivate alarm.

Snooze:

- Press SNOOZE/LIGHT to snooze alarm for 10 minutes

Nap:

- Hold NAP for 2 seconds to set nap duration
- Press +/- to adjust values and NAP to confirm
- Press NAP at anytime to start nap countdown

Date Display (Weekday or Day/Month/Date):

- Press the MINUS button to select date display

Backlight Intensity:

- Press SNOOZE/LIGHT button to adjust 4 levels or Off

Projection Intensity:

- Press to adjust 4 levels or OFF

Projection Rotate:

- Hold for 2 seconds to rotate projected image in 90 degree increments



PROJECTION ARM

Projection Arm:

- Rotates 180° to view projection on wall or ceiling
- Closes completely for travel

FOLD DOWN LEGS

Fold Down Legs:

- Open the legs fully (click) for a different viewing angle.

USB CHARGING PORT

USB Output: 1 Amp output

- Charge devices that self-regulate
- Must operate clock with power cable, to charge other devices
- Plug your device into the USB charging port
- The clock will show HELLO for 3 seconds
- The lightning bolt will flash while charging



WE'RE HERE TO HELP!

FIND FULL MANUALS, FAQs, AND MORE UNDER THE SUPPORT TAB HERE: <http://bit.ly/616-1950>

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



WARRANTY INFO

NEED MORE HELP?

Our knowledgeable customer support team is available: Monday-Friday, 8am-6pm CST. **Phone:** 1.608.782.1610

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

For Full Warranty Details, Visit:

www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

CANADA STATEMENT

This device complies with CNR Industry Canada license -exempt devices. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.