


BIKE HITCH

Setbacks



DERO
A PLAYCORE Company

www.dero.com | 1-888-337-6729

BIKE HITCH

Installation Instructions – Surface Mount


TOOLS NEEDED

Tape Measure
Marker or Pencil
Masonry Drill Bit
Drill (Hammer drill recommended)
Hammer
Wrench 9/16"
Level
Washers (for leveling if necessary)

RECOMMENDED BASE MATERIAL


Solid concrete is the best base material for installation. To ensure the proper anchors are shipped with your rack, ask your Dero Rack representative which anchor is appropriate for your application. Be sure nothing is underneath the base material that could be damaged by drilling.

1




Place the rack in the desired location. Use a marker or pencil to outline the holes of the flange onto the base material.

2




Drill the holes in accordance with the specifications shipped with the anchors. Make sure the holes are at least 3" away from any cracks in the base material.

3



Use washers to level rack if necessary.

4



Tap in anchors and follow your specific anchor instructions provided with the rack.



DERO
A PLAYCORE Company

www.dero.com | 1-888-337-6729

BIKE HITCH


Installation Instructions – In Ground Mount

TOOLS NEEDED


Level
Cement mixing tub
Shovel
Trowel
Hole coring machine with 4" bit
Access to water hose
Materials to build brace (see "Install Tip" at bottom of page)

RECOMMENDED BASE MATERIAL

Solid concrete is the best base material for installation. To ensure the proper anchors are shipped with your rack, ask your Dero Rack representative which anchor is appropriate for your application. Be sure nothing is underneath the base material that could be damaged by drilling.




Place corrosion resistant sleeve (min. 3" inside diameter) in sand pour bed in exact location where rack will be installed. Make sure top of sleeve is at same level as desired finished concrete surface. Fill sleeve with sand to keep it in place and prevent it from filling with concrete.



Pour concrete and allow to cure.


3



After appropriate cure time, dig out sand from sleeves and insert racks, making sure they are level and at the appropriate height. Pour in Por-Rok or epoxy grout and allow to set.

INSTALL TIP

An easy way to brace the Bike Hitch while the grout sets is to bolt two 1x4" boards together at one end and clamp them onto the legs of the Bike Hitch like a clothes pin.



DERO
A PLAYCORE Company

www.dero.com | 1-888-337-6729