

# Nudo FiberCorr™ Wall and Ceilings

Rev. 01 9/13

## Please Read Disclaimers:

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION!!

These guidelines are provided in good faith to help prevent any problems caused by common errors in installation. The manufacturer and/or distributor of this product shall not be held responsible for installation actions taken or not taken. There are many details of installation that are assumed to be general construction knowledge to experienced installers; which are not included in these instructions. These installation guidelines are intended to be strictly recommendations and are NOT to serve as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner and architect.

Nudo Products, Inc. does not accept any responsibility for job failure resulting from or associated with improper site environmental conditions.

**Safety Instructions:** When cutting or drilling, always wear protective glasses or goggles and a face mask which covers the face and mouth. Itching due to fibers may be avoided by the use of barrier creams on exposed skin areas.

### Tools Needed

- Circular saw with fine tooth carbide tipped saw blade
- Power drill with carbide bits
- Trowel recommended by adhesive manufacturer
- Trim Cutter

### Materials Needed

- FiberCorr Panels
- Heavy duty construction adhesive
- Seam Finishing: PVC molding trim
- Silicone Sealant (for installation in high moisture areas)
- Non-abrasive cleaner, soap and water, mineral spirits, for use in clean-up
- Rags
- Sandpaper for roughing up walls
- Personal protection equipment (goggles & mask)
- Tape measure
- Saw horses
- Painter's tape
- Plywood larger than panels

## Preparation:

### Storage



All FiberCorr panels should be stored indoors on a solid, flat, dry surface. Do not stand panels on edge or stack on fresh concrete floor or any other surface that emits moisture. Lay panels flat with proper support on the ends of panels. Optimum storage conditions are 60°F (16°C) to 75°F (24°C) and 35% to 55% relative humidity.

### **Prior to Installation**

Installation should NOT begin until building is enclosed (windows and doors installed). Permanent heating and cooling equipment is in operation, and residual moisture from plaster, concrete, etc. is dissipated. Prior to installation, the installer must determine that the environmental conditions meets or exceeds all requirements specified in the installation guidelines. Before installing remove packaging materials. Allow the panels to acclimate to the room temperature and humidity for 48 hours before installing. Acclimation temperature range should be 60° to 75°F (16°C to 24°) and relative humidity should be 35% to 55%. Ideally, the room temperature and humidity during acclimation and installation should be the same as the final operation conditions.

### **Wall Preparation**

Panels can be installed over solid wall surfaces (gypsum board, concrete board, wood, cinder block, etc.) or directly over framing studs. When installing over solid surfaces, walls should be flat and even. Remove high spots and fill in low spots prior to beginning installation. Remove wallpaper, soluble or loose paint, and other foreign matter that may interfere with the adhesive bond. The wall substrate must be dry and free from dirt, dust and grease. Painted surfaces will not allow solvent-free or solvent-based adhesives to dry. The substrate must be porous to enabling the adhesive to cure and achieve full bond strength. Painted surfaces must be perforated to rough up the wall or gouged with a minimum of 20-grit heavy duty sandpaper to break the moisture barrier of the paint. All loose paint and dirt must be removed prior to installation. New gypsum board or drywall should NOT be painted or primed. Tapered joints need only a fill and taped coating using a setting joint compound. A finish coat is not necessary or desirable. Please read adhesive manufacturers recommendation for further preparation not covered in this paragraph.

### **Environmental Conditions**


In *high humidity*, acclimate panels in operational room conditions for 48 hours prior to installation. It is imperative that moisture is sealed at the entry points with silicone sealant. Failure to do so may result in the substrate warping, curling, delamination or bond line separation. Use an adhesive that is recommended for high humidity, following the manufacturer's application guidelines. Check with the local building codes for specific requirements. In *low temperature* conditions, acclimate panels in operational room conditions for 48 hours prior to installation. Use an adhesive recommended for low temperature conditions, following the manufacturer's application guidelines. Check with the local building codes for specific requirements. Do NOT use FiberCorr panels, in high temperature conditions, exceeding 130° F (55°C). Prolonged exposure to direct sunlight MAY CAUSE the panels to fade and/or rapid expansion. Please use extreme caution when installing panels in these type environments.

### **Pre-Installation Inspection**

Panels should be inspected upon receipt. Nudo Products, Inc. inspects composite panels for physical and cosmetic abnormalities prior to shipment; however it is the installer's responsibility to fully inspect all panels for defects prior to installation. If they panels are not acceptable, please contact Nudo Products, Inc. customer services immediately. DO NOT INSTALL QUESTIONABLE PANELS! Nudo Corporation will NOT be responsible for installation or removal cost of unacceptable panels.



## Pre-Install Planning



Measure Area. Set true plumb line. Panels should be pre-fit (and pre-drilled if rivets are required) prior to fastening and/or adhering to substrate. Adhesive should be applied AFTER all cutting and drilling is complete. Cove base molding should not restrict panel, but allow for expansion and contraction. Poured molding should be completed prior to installation of panels. Cut panels 1/4" short of where the base molding will extend.

## Installation Steps

### Method

- First panel installed should be set true with a plumb line
- Trim panel to fit and cut out any fixture openings.
- Cut moldings as needed for proper fit. The divider, ISC & OSC moldings may need to be cut to accommodate ceiling and base finishes.
- Start installation of molding in any inside corner, mark plumb line (48<sup>1/8</sup>) for vinyl trim.
- When installing over solid substrate apply adhesive to 100% of backside of panels.
- Insert panel into inside corner molding, place panel into corner of wall and align with plumb line.
- If using an end cap on top or bottom of panels, slide it completely on to panel prior to adhering to wall
- Place panel on wall leaving appropriate room for expansion and contraction
- Once panel is placed on wall, use roller to remove any air pockets
- Install dividing trim on first panel.
- Apply adhesive to the next panel, slide into the first panel division bar, align with plumb line, and use roller to remove any air bubbles.
- Repeat with next panel.
- Prior to installing the last panel on the first wall, insert an inside corner on the leading edge of the panel. The first panel on the new wall will slide into the last panels inside corner of the existing wall, completing the transition
- Continue the method working in one direction around the room.


## Adhering to Wall



The method of adhering should be determined by the substrate applying to solid or frame stud. Typically, using an adhesive or fasteners exclusively will suffice, but sometimes a combination of both may be necessary. A vapor barrier may be required also in high moisture areas. Check with your local building codes to determine any restrictions or guidelines. You should use construction grade adhesive that is recommended for your environment/temperature/humidity conditions and have 100% coverage when applying. Adhesive should be applied to the entire back side of the panels about 1/4" (6.4 mm) thick. Follow

the adhesive manufacturer's recommendation for trowel, room conditions and application methods. When applying with adhesive, it is imperative to secure the FiberCorr panels with an adjustable rolling tool to properly "set" the panel and substrate.

### Spacing




All FiberCorr panels will have some expansion and contraction due to changes in temperature and environment. It is important to allow a 1/8" gap at the ceiling and panel base. Allow a 1/16" gap between panels and division bars. If face mounted moldings. Allow more space for expansion and contraction of FiberCorr panels longer than 8' and in areas with high fluctuations in temperature. Pre-drilled holes should be slightly larger than the diameter of fastener shank to allow for normal expansion and contraction. Note: Allow for expansion of FiberCorr panels when installing around pipes, conduits, electrical outlets, etc.

### Molding



Vinyl moldings can be used for installation. Cut moldings as needed for proper fit. The divider, ISC & OSC moldings may need to be cut to accommodate ceiling and base finishes. Place moldings on panels before fastening edges, if required. Always use moldings in high moisture areas. The use of trim moldings and silicone sealant with FiberCorr panels is recommended to achieve a moisture resistant installation. Cut moldings to size and place silicone sealant into channel of moldings during installation. Place moldings on panels before fastening, if required. Follow silicone sealant manufacturer's recommendations for installation.

### Fasteners



In high moisture areas or certain situations, FiberCorr panels should be installed with non-corroding fasteners. We recommend plastic pin rivets, chrome pin rivets, on piece nylon rivets, stainless nails or screws. Fasteners should be installed to fit snug, but should not be over tightened. Carefully select the proper length and width of rivet fastener for the covered project substrate.

### Finish Work

Remove all adhesive residues, cleaning panels thoroughly with warm water, a non-abrasive detergent and cloth. For cleaning with solvent based adhesive, use mineral spirits to remove residue.

## Ceiling Suspension System

### Pre- Installation Inspection



Install suspended ceiling system to manufacturer's specifications.

Ceiling Panels should be inspected upon receipt. Nudo Products, Inc. inspects FiberCorr ceiling panels for physical and cosmetic abnormalities prior to shipment; however it is the installer's responsibility to fully inspect all ceiling panels for defects prior to installation. If the panels are not acceptable, please contact Nudo Products, Inc. customer services immediately. **DO NOT INSTALL QUESTIONABLE PANELS!** Nudo Corporation will **NOT** be responsible for installation or removal cost of unacceptable panels.

### Installing Ceiling Panels



Prior to installing remove all adhesive residues with a clean cloth. Slightly tilt panels, lift above suspended framework, and gently rest on cross tee and main beam edge.

### Border Panels



Border panels may require field cutting. Measure and cut border panels individually. Using a leftover cross tee or main beam section as a straight edge, cut panels face up with a circular saw.

### Lighting and Other Fixtures



Lighting and other fixtures must be supported by the grid, not by the ceiling panels. Depending on the size and weight of the fixtures, extra hangers may be required.