

installation instructions:

Wood Corbels

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear proper protective gear.

Follow fixture, power tools, paint manufacturers' instructions, and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- Electric Drill
- Hammer
- Wood Glue
- Screws
- Nails

SPECIAL INSTRUCTIONS AND NOTES

- Clean installation surface and back of corbel of all dirt and dust with a clean cloth.
- Make sure that the surface of the corbel are completely dry before installation.
- Measure and mark the location where the corbel is going to be installed.
- Be sure to consult a professional about painting or staining this product.

STEP BY STEP INSTRUCTIONS

1. Lay the corbel face down on a soft surface that will not damage the corbel detail.
2. Apply wood glue to the installation areas of the corbel, top and/or back.
3. When pressing the corbel up against the surface, some glue will seep out. Wipe these areas clean to ensure a quality installation.
4. Install by either (A) toe nailing the corbel from the sides, (B) screwing straight through the corbel C) screwing through the wall from behind, or (D) use the keyholes on the back of the corbel to hang the bracket.

When ordering a corbel for your countertop installation, keep in mind the corbel must be sufficiently supported by an adequate fastening system and structure such as stud wall or reinforced cabinet backing. Installation of a heavy duty countertop corbel on a weak support structure will result in failure of the total system. This is why it is important to consider, and consult with a design engineer when necessary, all aspects of the countertop installation.

In instances where the corbels will be adhered directly to a granite counter we suggest only using adhesives and not drilling into the countertop. Drilling during installation can weaken the stone or possibly crack the counter.

EXAMPLE INSTALLATION DIAGRAMS

