


HOME DECORATORS COLLECTION

BF-25141 SCRAPBOOKING BASE 36"H×42"W×20"D

INV#16063













ASSEMBLY INSTRUCTIONS

Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


PARTS LIST		
A  TOP PANEL-1PC	B  LEFT SIDE PANEL-1PC	C  RIGHT SIDE PANEL-1PC
D  ADORNING PANEL-1PC	E  UP STAND PANEL-1PC	F  ACROSS PANELS-2PCS
G  ACROSS FRAME-1PC	H  DOWN STAND PANEL-1PC	I  BOTTOM FRAME-1PC
J  UP BACK PANEL-1PC	K  DOWN BACK PANEL-1PC	L  LEFT SMALL DRAWER PANEL FRONTS-2PCS

M




RIGHT SMALL
DRAWER PANEL FRONTS-2PCS

N




SMALL LEFT
DRAWER PANEL SIDES-4PCS

O




SMALL RIGHT
DRAWER PANEL SIDES-4PCS

P




SMALL
DRAWER PANEL BACKS-4PCS

Q



DRAWER PANEL BOTTOMS-8PCS

R




LARGE
DRAWER PANEL STANDS-8PCS

S




SMALL
DRAWER PANEL STANDS-8PCS

T




DRAWER ACROSS PANELS-4PCS

U




LEFT MIDDLE
DRAWER PANEL FRONT-1PC

V




RIGHT MIDDLE
DRAWER PANEL FRONT-1PC

W



MIDDLE LEFT
DRAWER PANEL SIDES-2PCS

X




MIDDLE RIGHT
DRAWER PANEL SIDES-2PCS

Y




MIDDLE
DRAWER PANEL BACKS-2PCS

Z




LEFT LARGE
DRAWER PANEL FRONT-1PC

A1




RIGHT LARGE
DRAWER PANEL FRONT-1PC

B1




LARGE LEFT
DRAWER PANEL SIDES-2PCS

C1



LARGE RIGHT
DRAWER PANEL SIDES-2PCS


D1



LARGE
DRAWER PANEL BACKS-2PCS


NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

E1 11mm × 1"




BOLTS-12PCS

F1



ALLEN WRENCH-1PC

G1



FEET-4PCS

H1



KNOBS-8PCS


I1

8mm × 5/8"




SCREWS-8PCS

J1




DOWELS-12PCS

K1



OUTER SLIDES-16PCS


L1



INNER SLIDES-16PCS

M1


6mm × 1/2"



SCREWS-72PCS

N1


6mm × 1"



SCREWS-64PCS

O1


8mm × 1"



SCREWS-3PCS


P1

7mm × 7/8"




SCREWS-4PCS

Q1



GECKOS-4PCS


R1



PLASTIC BELTS-2PCS


S1

6mm × 3/4"



SCREWS-4PCS

T1




HOOKS-4PCS

U1



CAM-TOOL-1PC

V1



CAM-BOLTS-26PCS


NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

W1



CAM-LOCKS-26PCS


X1



FILE HANGERS-4PCS

Y1

6mm × 3/8"



SCREWS-24PCS


Z1

11mm × 1"



BOLTS-4PCS



A2



NUTS-4PCS




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS





1). ASSEMBLE THE OUTER SLIDES (K1).

- ATTACH 4 OUTER SLIDES (K1) TO RIGHT SIDE PANEL (C) USING 12 SCREWS (M1).





2). ASSEMBLE THE OUTER SLIDES(K1).

- ATTACH 4 OUTER SLIDES(K1) TO LEFT SIDE PANEL(B) USING 12 SCREWS(M1).




3). ASSEMBLE THE OUTER SLIDES (K1).

- ATTACH 6 OUTER SLIDES (K1) TO UP STAND PANEL USING 18 SCREWS (Y1).




4). ASSEMBLE THE OUTER SLIDES(K1).

- ATTACH 2 OUTER SLIDES(K1) TO DOWN STAND PANEL USING 6 SCREWS(Y1).




5). ASSEMBLE THE BACK PANEL (J/K).

- ROTATE 3 CAM-BOLTS (V1) INTO THE HOLES IN THE UP BACK PANEL (J).
- PLACE 3 CAM-BOLTS (V1) INTO THE HOLES IN THE DOWN BACK PANEL (K) AND ATTACH USING 3 CAM-LOCKS (W1).




6). ASSEMBLE THE LEFT SIDE PANEL (B).

- ROTATE 4 CAM-BOLTS (V1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE 4 CAM-BOLTS (V1) INTO THE HOLES IN THE BACK PANEL (J/K) AND ATTACH USING 4 CAM-LOCKS (W1).




7). ASSEMBLE THE DOWN STAND PANEL (H).

- INSERT 2 NUTS (A2) INTO THE HOLES IN THE DOWN STAND PANEL (H).
- ATTACH THE BOTTOM FRAME (I) TO DOWN STAND PANEL (H) USING 2 BOLTS (Z1).




8). ASSEMBLE THE ACROSS FRAME (G).

- INSERT 2 NUTS (A2) INTO THE HOLES IN THE DOWN STAND PANEL (H).
- ATTACH THE ACROSS FRAME (G) TO DOWN STAND PANEL (H) USING 2 BOLTS (Z1).




9). ASSEMBLE THE UP STAND PANEL (E).

- ROTATE 2 CAM-BOLTS(V1) INTO THE HOLES IN THE ACROSS FRAME(G).
- PLACE 2 CAM-BOLTS(V1) INTO THE HOLES IN THE UP STAND PANEL(E) AND ATTACH USING 2 CAM-LOCKS(W1).




10). ASSEMBLE THE FRAME (G/I).

- ATTACH THE FRAME(G/I) TO LEFT SIDE PANEL(B) USING 4 BOLTS(E1).




11). ASSEMBLE THE FRAME (G/I).

- ROTATE 4 BOLTS (E1) INTO THE HOLES IN THE FRAME (G/I).




12). ASSEMBLE THE ACROSS PANELS (F).

- ROTATE 2 CAM-BOLTS(V1) AND INSERT 2 DOWELS(J1) INTO THE HOLES IN THE LEFT SIDE PANEL(B).
- PLACE 2 CAM-BOLTS(V1) INTO THE HOLES IN THE ACROSS PANELS(F) AND ATTACH USING 2 CAM-LOCKS(W1).




13). ASSEMBLE THE RIGHT SIDE PANEL (C).

- ROTATE 6 CAM-BOLTS(V1) AND INSERT 2 DOWELS(J1) INTO THE HOLES IN THE RIGHT SIDE PANEL(C).
- PLACE 6 CAM-BOLTS(V1) INTO THE HOLES IN THE PANEL(F/J/K) AND ATTACH USING 6 CAM-LOCKS(W1).




14). ASSEMBLE THE FRAME (G/I).

- ROTATE 4 BOLTS (E1) INTO THE HOLES IN THE FRAME (G/I).




15). ASSEMBLE THE FEET (G1).

- ROTATE 4 FEET (G1) INTO THE HOLES IN THE SIDE PANEL (B/C).




16). ASSEMBLE THE ADORNING PANEL (D).

- ATTACH THE ADORNING PANEL (D) TO TOP PANEL (A) USING 3 SCREWS (01).



17). ASSEMBLE THE TOP PANEL (A).


- ROTATE 9 CAM-BOLTS (V1) AND INTO THE HOLES IN THE TOP PANEL (A).
- PLACE 9 CAM-BOLTS (V1) INTO THE HOLES IN THE PANEL (B/C/E/J) AND ATTACH USING 9 CAM-LOCKS (W1).



18). ASSEMBLE THE SMALL DRAWERS.


- ATTACH SMALL DRAWER PANEL SIDE(N/O) USING 4 SCREWS(N1).
- ATTACH THE KNOB(H1) TO SMALL DRAWER PANEL FRONT(L/M) USING 1 SCREW(I1).
- INSERT THE SMALL DRAWER PANEL BOTTOM(Q) INTO THE SLOTS IN THE SMALL DRAWER PANEL SIDE(N/O).
- ATTACH SMALL DRAWER PANEL BACK(P) BETWEEN SMALL LEFT DRAWER PANEL SIDE(N) AND SMALL RIGHT DRAWER PANEL SIDE(O) USING 4 SCREWS(N1).
- INSERT PANEL(R/S/T) INTO THE SLOTS IN THE SMALL DRAWER.

Arrow faces drawer front



19). ASSEMBLE THE INNER SLIDES(L1).


- ATTACH THE 2 INNER SLIDES(L1) TO SMALL DRAWER PANEL SIDE(N/O) USING 6 SCREWS(M1).



20). ASSEMBLE THE MIDDLE DRAWERS.

- ATTACH MIDDLE DRAWER PANEL SIDE (W/X) USING 4 SCREWS (N1).
- ATTACH THE KNOB (H1) TO MIDDLE DRAWER PANEL FRONT (U/V) USING 1 SCREW (I1).
- INSERT THE MIDDLE DRAWER PANEL BOTTOM (Q) INTO THE SLOTS IN THE MIDDLE DRAWER PANEL SIDE (W/X).
- ATTACH MIDDLE DRAWER PANEL BACK (Y) BETWEEN MIDDLE LEFT DRAWER PANEL SIDE (W) AND MIDDLE RIGHT DRAWER PANEL SIDE (X) USING 4 SCREWS (N1).


Arrow faces drawer front



Arrow faces drawer front

21). ASSEMBLE THE INNER SLIDES(L1).


- ATTACH THE 2 INNER SLIDES(L1) TO MIDDLE DRAWER PANEL SIDE(W/X) USING 6 SCREWS(M1).



22). ASSEMBLE THE LARGE DRAWERS.

- INSERT 2 DOWELS(J1) INTO THE HOLES IN THE LARGE DRAWER PANEL FRONT(Z/A1) AND ATTACH LARGE DRAWER PANEL SIDE(B1/C1) USING 4 SCREWS(N1).
- ATTACH THE KNOB(B1) TO LARGE DRAWER PANEL FRONT(Z/A1) USING 1 SCREW(I1).
- INSERT LARGE DRAWER PANEL BOTTOM(Q) INTO THE SLOT IN THE LARGE DRAWER PANEL SIDE(B1/C1).
- INSERT 2 DOWELS(J1) INTO THE HOLES IN THE LARGE DRAWER PANEL BACK(D1) USING 4 SCREWS(N1).
- INSERT THE FILE HANGERS(X1) INTO THE CUT-OUT OF THE FRONT & BACK DRAWER PANELS.


ARROW FACES DRAWER FRONT



ARROW FACES DRAWER FRONT

23). ASSEMBLE THE INNER SLIDES(L1).

- ATTACH THE 2 INNER SLIDES(L1) TO LARGE DRAWER PANEL SIDE(B1/C1) USING 6 SCREWS(M1).




24). ASSEMBLE THE DRAWERS.

- INSERT ALL DRAWERS INTO THE SLIDERS.



Warning

The anti-tip hardware must be used as part of assembly!



25). ASSEMBLE THE HOOKS(T1).

- ATTACH 2 HOOKS(T1) USING 4 SCREWS(S1) IN THE PREDRILLED HOLES OF REAR TOP PANEL(A).



26). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO WALL, PLEASE REFER TO THE REAR TOP PANEL'S HOLES DISTANCE AND HEIGHT.
- PUT 4 GECKOS(Q1) INTO HOLES IN THE WALL, AND ROTATE 4 SCREWS(P1) INTO THE GECKOS(Q1).
- CONNECT THE TWO HOOKS(T1) WITH A PLASTIC BELT(R1).