



# Use and Care Guide

## 1.25 in. and 1.5 in. ABS Threaded Sump Pump Check Valve

Item # 1001091723  
Model # THD1021


**EVERBILT**




### TOOLS REQUIRED



Safety Goggles




Tape Measure




Hacksaw or PVC Cutter



Flathead Screwdriver



Primer




Cement


ABS to PVC Primer and Cement

### Installation


1. Make sure your pump is unplugged..
2. The Everbilt 1.25 in. and 1.5 in. ABS Threaded Sump Pump Check Valve features dual 1.25 in. or 1.5 in. threads that fits into any 1.25 in. or 1.5 in. discharge sump pump.
3. Apply thread sealing tape to the threads. Make sure the factory weep hole remains exposed if your pump requires it.
4. The threaded end will also accept an 1.25 in. or 1.5 in. flexible coupling for in line installations.
5. The discharge end of the check valve will accept flexible hose, 1.5 in. PVC pipe, or an 1.25 in. flexible coupling.
6. Attach flexible hose or couplings with hose clamps. **Do not exceed 15 in-lbs. Do not overtighten.**
7. Plug in your pump. Cycle your system a few times and check for leaks.



Pump to Flexible Hose



Pump to Solvent Weld  
1.5" SCH40 PVC Pipe



Pump to Flexible  
Coupling



Flexible Coupling to  
Flexible Coupling

### Safety Information



**WARNING:** Always disconnect power to your pump and release system pressure before servicing.

### Warranty

This product is warranted to the original consumer purchaser to be free from defects in material and workmanship for a period of one year from the date of purchase. For additional details and questions, please contact Everbilt Customer Service at 1-877-297-6069.

**EVERBILT**

HOMEDEPOT.com

Please contact 1-877-297-6069 for further assistance.