

Use & Care Instructions

- Distribute weight evenly on shelves, place heavier items on bottom shelves.
- Load shelves from bottom up to prevent unit from becoming too heavy.
- Carefully place items on shelves - do not drop or throw items onto shelves.
- Do not climb on shelves or attempt to use as a ladder.
- When moving shelves - remove all items first.
- Do not attempt to lift or tilt shelves - unit could tip over or become damaged.
- Use only on hard, flat and level surface.
- ***RISK OF TRAPPING HAND/FINGER*** – use caution when opening or folding to insure that fingers and hands do not become entrapped.
- Maximum weight capacity is **100lbs** for the top shelf and **50lbs** for middle and lower shelf shelf with casters.
- **Failure to follow these instructions could result in serious personal injury, failure of unit or both.**