

Siliconizer Crack Filler Instructions

Surface Preparation: All surfaces must be clean and free of contaminants such as dirt, grease, mildew, oil, rust, loose or badly cracked sealant and paint.

Mildewed Surfaces: Any existing mildew on the surface must be completely killed and removed prior to the application of new sealant. To remove mildew, scrub surface with a long-handled brush and a mixture of one-quart household bleach and three quarts of warm water. Rinse completely and let dry.

Previously Caulked Surfaces: It is critical to remove as much old sealant as possible before applying new caulk, specially if it is cracked, eroded or pulled away from the joint.

New Construction: Make sure the adjacent surfaces are clean, dry and dust free. For both interior and/or exterior use, apply one coat of *LANCO® Acrylic Wall and Roof Primer/Sealer™ AS-210*. Let dry four hours before applying the sealant.

Painted Areas: Scrape off any loose paint in the joints and apply one coat of *LANCO® Acrylic Wall and Roof Primer/Sealer™ AS- 210*. Let dry four hours before applying the sealant.

Note: Apply at temperatures above 50oF (10oC) and when no precipitation is expected within 72 hours.

Application: For best results, follow these instructions:

(1) **SHRINKAGE CRACKS** (less than 1/32" wide): Prime with *LANCO® Acrylic Roof and Wall Primer/Sealer™ AS- 210* and let dry. Apply *LANCO® Siliconizer Elastomeric Crack Filler™* over crack and two inches to each side of it.

(2) **CRACKS 1/32" OR BIGGER:** Any cracks bigger than 1/32" should be pouted out to 1/4" wide and 1/4" deep. Clean crack with water, and let dry. Prime with *LANCO® Acrylic Wall and Roof Primer/Sealer™ AS-210* and let dry four hours. Fill joint completely and two inches to each side with *LANCO® Siliconizer Elastomeric Crack Filler™* and let dry 24 hours.

(3) **JOINTS:** Clean joints with water and let dry. Prime with *LANCO® Acrylic Roof and Wall Primer / Sealer™ AS- 210*. And let dry. Fill them with backing rod and cover with *LANCO® Siliconizer Elastomeric Crack Filler™ 11/16"* over surface and two inches to each side of joint.

Coverage: Depends on depth and size of holes and cracks. Approximately 34 linear feet of 1/4" bead per 10.1 oz. cartridge.

Cleanup: Clean all equipment immediately after use with warm soapy water.

Drying Time: Under standard conditions, a 1/32" bead will be fully cured in 24 hours; however, this may vary depending on weather conditions. Joints bigger than 1/32" may need 48 hours. Full cure takes place in seven days. Let dry two hours before painting with latex, and 24 hours for alkyd paints.

Caution: Use only with adequate ventilation. Do not take internally. Keep out of reach of children.