

HONDA

Power

Equipment

IMPORTANT INFORMATION

HS720A HANDLEBAR TIGHTENING TORQUE

During initial setup, tighten the two handlebar flange nuts to 52 in-lb (5.9 N•m). This torque is achieved by tightening the flange nuts approximately 1/4 turn after the bolt free-play is eliminated. **Do not over-tighten the nuts.** Over-tightening these nuts will cause excessive vibration to be transferred to the upper handlebar.

(AA type shown)

