


FRONT BASE LENGTH: 7' 5"

SIDE BASE LENGTH: 2' 6 11/16"

HEIGHT: 3' 9 1/4"



We thank you for choosing an Australian made shed
For further assistance please visit our detailed instructional video library at
<http://www.abscosheds.com.au/watch-videos>

At ABSCO Industries we are always looking to be number ONE
Please let us know what you think of our instructions
Feedback makes us better
feedback@absco.com.au

GENERAL INSTRUCTIONS

Before commencing any assembly, read through these instructions in detail to gain a thorough understanding of assembly methods and associated details.

Unpack the carton and carefully identify and check off all the parts against the parts described and illustrated on "COMPONENTS PACKING LIST" pages.

SITE PREPARATION

The site for the shed must be level. An uneven surface may result in misalignment of parts.

It is recommended that the shed be set on a 4" concrete slab and anchored down appropriately (refer to last page for details).

Anchor sets suitable for concrete are supplied as standard items with this product.


TOOLS REQUIRED



13/32"
(Steel)

13/32"
(Masonry)

OPTIONAL TOOLS



(Supplied)

SAFETY NOTES

Some parts may have sharp edges. It is advisable to wear gloves when handling these items and safety glasses if drilling holes. Sensible shoes are highly recommended.

Do not erect your shed in windy conditions.



Ensure that the shed is securely anchored to a solid foundation immediately after construction is completed.

It is recommended to erect the shed with the assistance of another person.



SPLIT SHEET 39B INTO 2x 1' 15/16" WIDE SHEETS


This shed comes with a perforated sheet 39C that is designed to be split into two smaller sheets (39C)

SPLITTING SHEET 39C						
QTY	COMPONENT DESCRIPTION	PART No.		QTY	COMPONENT DESCRIPTION	PART No.
1	 STEEL SHEET 3' 8 1/2" LONG 2' 6 7/16" WIDE	39C	=	2	 STEEL SHEET 3' 8 1/2" LONG <u>1' 15/16" WIDE</u>	39C

THESE SHEETS HAVE SHARP EDGES. ONCE SEPARATED PLEASE USE APPROPRIATE FOOT AND HAND PROTECTION WHEN HANDLING.

In order to split the sheet lay it on the ground and lift and fold one end until the perforations have cleanly snapped.

Discard the middle piece as scrap when convenient. Fold the scrap piece in half 2-3 times and throw in bin.



CHECK SHEET FOR PERFORATIONS



FOLD FIRST SECTION OF SHEET UNTIL FREE
































FOLD MIDDLE SECTION OF SHEET UNTIL FREE


































DISCARD MIDDLE PIECE


COMPONENTS PACKING LIST - CHECK OFF ALL COMPONENTS

MAIN PACK CARTON							
QTY	DESCRIPTION	PART #	CHK	QTY	DESCRIPTION	PART #	CHK
2	 STEEL SHEET 3' 8 1/2" LONG 2' 6 7/16" WIDE	44Z		2	 STEEL SHEET 3' 8 1/2" LONG 2' 6 7/16" WIDE	44W	
1	 STEEL SHEET 2' 6 7/8" LONG 2' 6 7/16" WIDE	43W		1	 STEEL SHEET 3' 8 1/2" LONG 1' 15/16" WIDE	39C	
1	 STEEL SHEET 2' 6 7/8" LONG 2' 6 7/16" WIDE	43X		1	 STEEL SHEET 3' 8 1/2" LONG 2' 6 7/16" WIDE	44Y	
1	 STEEL SHEET 2' 6 7/8" LONG 2' 6 7/16" WIDE	43Y		1	 STEEL SHEET 3' 6 1/8" LONG 2' 6 7/16" WIDE	DoorR	
1	ANCHORS 4 PACK	ANCHORSET4		1	 STEEL SHEET 3' 6 1/8" LONG 2' 6 7/16" WIDE	DoorL	
INSTRUCTIONS & FITTINGS PACK							
2	 CHAIN 1' 5 11/16" LONG	FAST073		4	 3/16" x 1/2" PAN HEAD SCREW	FAST002	
7	 2 1/2" BUTT HINGE 6 HOLE	FAST012A		8	 3/16" NUT	FAST005	
2	 DOOR PLATE 6 1/2"	CO12A		6	 CHANNEL JOINER 7 7/8"	ZACSJ	
4	 WAFER TEK SCREW	FAST014		1	 POP RIVET GUN		
1	 POP RIVET x50	PACK12		1	 PADBOLT	FAST006	
PSTKDBL - DOUBLE DOOR FITTINGS PACK							
3	 PADBOLT	FAST006		2	 PADBOLT HASP	FAST007	
1	 8G x 3/8 SELF TAPPING SCREWS x 220	PACK220		1	 SCREW PACK 12	PACK12P	
1	 3mm (0.18") DRILL BIT	DRILL		1	 PHILLIPS HEAD DRIVER BIT	FAST038	
PACK12P - SCREW PACK 12							
12	 POP RIVET	FAST009		12	 3/16" x 1/2" COUNTERSUNK SCREW & NUT	FAST004 FAST005	
8	 3/16" x 1/2" PAN HEAD SCREW	FAST002		8	 3/16" NYLOCK NUT	FAST003	

COMPONENTS PACKING LIST - CHECK OFF ALL COMPONENTS


23083BSM CHANNEL PACK							
QTY	DESCRIPTION	PART #	CHK	QTY	DESCRIPTION	PART #	CHK
1	 CHANNEL 3' 8 3/8" NOTCHED ONE END	54PL		1	 CHANNEL 3' 8 3/8" NOTCHED ONE END	54PR	
1	 CHANNEL 3' 8 7/16" STRAIGHT	54SL		1	 CHANNEL 3' 8 7/16" STRAIGHT	54SR	
1	 CHANNEL 3' 8 7/16" STRAIGHT	54TL		1	 CHANNEL 3' 8 7/16" STRAIGHT	54TR	
2	 CHANNEL 3' 7 7/8" NOTCHED ONE END	54RL		2	 CHANNEL 3' 7 7/8" NOTCHED ONE END	54RR	
1	 CHANNEL 3' 8 3/8" NOTCHED ONE END	81DL		1	 CHANNEL 3' 8 3/8" NOTCHED ONE END	81DR	
1	 CHANNEL 1' 3 7/16" STRAIGHT	79AL		1	 CHANNEL 3' 10 5/16" STRAIGHT	79AR	
4	 CHANNEL 2' 6 7/16" STRAIGHT	58C		1	 CHANNEL 3' 6 1/8" STRAIGHT	58T	
1	 CHANNEL 3' 6 1/8" STRAIGHT	58W		2	 CHANNEL 3' 6 1/8" STRAIGHT	58Y	
2	 CHANNEL 2' 6 7/16" STRAIGHT	61G		2	 CHANNEL 2' 6 7/16" STRAIGHT	81J	
1	 JAMB 3' 10 5/16" NOTCHED BOTH ENDS	90AL		1	 JAMB 1' 3 7/16" NOTCHED BOTH ENDS	90AR	
1	 JAMB 3' 6 1/8" STRAIGHT	91J		2	 JAMB 3' 8 1/2" NOTCHED BOTH ENDS	91K	
2	 JAMB 3' 3 " STRAIGHT	91L		1	 JAMB 3' 6 15/16" STRAIGHT	91S	
1	 JAMB 3' 8 1/8" STRAIGHT	91A		2	 LIP 2' 6 7/8"	87H	
2	 LIP 2' 5 1/2"	88Z					
ANCHORSET - ANCHORS (4 PACK)							
4	 MASONRY ANCHOR Ø0.39x2"	FAST015		4	 M10x20mm HEX HEAD BOLT	FAST018-1	
4	 ANCHOR BRACKET	BKT01		4	 M10 HEX NUT	FAST018-2	

NOTE: THE TEXT MARKED ON ALL PARTS MUST BE SHOWN ON THE SAME SIDE AS EACH OTHER.





STEP 1.

Position the channels and the CSJ so the center of the CSJ is in line with the end of each channel to be joined together.




STEP 2.

Join the first channel to the CSJ by inserting the center of the CSJ (on an angle) to the end of the channel where the JOIN>> text is marked. Push down one side of the CSJ until you hear a 'click'.



STEP 3.




Join the second channel to the CSJ by positioning the <<JOIN end of the channel at the center of the CSJ (on an angle). Push the CSJ into the channel until you here a 'click'.



FINISHED CHANNEL

The joined channels should now look like the picture above with the CSJ positioned equally inside of the joined channels.


DRILL 4 x 1/8" (2 PER SIDE) HOLES TO SECURE SECTIONS TOGETHER. (THESE SCREWS MAY HAVE TO BE TEMPORARILY REMOVED AND REPLACED DURING LATER ASSEMBLY)




PRE-ASSEMBLY: JOINING SPLICED CHANNELS

NOTE: JOIN TOGETHER 12 X CHANNEL SECTIONS USING 6 X CHANNEL JOINERS (PART CSJ)


NOTE: SOME CHANNELS HAVE HOLES IN THEM - YOU WILL NEED TO RE-DRILL HOLES ON ANY CHANNEL WHERE THE CSJ JOINING CHANNEL COVERS HOLES ON THE CHANNELS YOU ARE CONNECTING



VIEW OF WALL COMPONENTS




VIEW OF LID COMPONENTS





ABSCO ASSEMBLY INTRODUCTION


The snaptite assembly system locks most perimeter channels to all roof and wall sheets without the need for tools and fasteners.



To pre-assemble the four wall panels and two roof panels, the perimeter channels are secured to the top and bottom of each panel using the snaptite system, as detailed on the following pages wherever you see the symbol.



After joining sheets together, position channel over one end of the sheets, gently tapping it over the snaptite lugs, working along the sheets to the other end.





Position sheets on timbers, trestles or partly over edge of concrete slab.


Each perimeter channel must finish flush with the edges of the sheets. The snaptite system allows adjustment for this process by simply tapping the channel along the sheets until each end is neatly flush. If you need to remove channels from the panels, pull the channel along the panel from opposing ends. You may need someone to help with this.

FASTENING SYMBOLS

 **D** Join components together by pre-drilling the holes first. Use one component as a template to mark where the holes are. Drill with 3mm drill bit.

 Join components together with one screw at this location only, as some channel sections have extra holes that are not required for this model of garden shed

 Do not join components together at this location yet, as the screw may obstruct further assembly of other components




POP RIVETS




NUT & BOLT SET


REAR PANEL ASSEMBLY




SIDE PANEL ASSEMBLIES



LID ASSEMBLY





LID ASSEMBLY




A SINGLE PADBOLT IS TO BE FIXED TO THE UNDERSIDE OF THE LID. THE MIDDLE OF THE PADBOLT IS TO BE $1 \frac{27}{64}$ " TO THE RIGHT OF THE CENTRELINE OF THE LID.

THE BOLT IS ORIENTATED AS PICTURED. THE CLOSEST PAIR OF HOLES ARE $3 \frac{1}{4}$ " FROM THE EDGE OF THE LID. USING THE PADBOLT AS A TEMPLATE MARK THE FOUR HOLES AS SHOWN AND DRILL USING A $\frac{15}{64}$ " DRILL BIT.




NOTE: THIS BOLT REQUIRES A $\frac{13}{32}$ " HOLE TO BE DRILLED INTO THE INSIDE FACE OF THE TOP CHANNEL OF THE FRONT PANEL. THIS IS BEST DONE AFTER THE STRUCTURE HAS HAD ITS FINAL ALIGNMENT AND BEEN ANCHORED.




USE FOUR FAST002 BOLTS EACH WITH A FAST005 NUT TO STANDOFF THE PADBOLT BEFORE FASTENING WITH ANOTHER NUT AS PICTURED.

LID ASSEMBLY





DOOR PANEL ASSEMBLY




FRONT PANEL ASSEMBLY

NOTE: FIT FAST001 SCREWS THROUGH 54R CHANNELS AT TOP AND BOTTOM OF 39C SHEETS 1ST THEN SQUEEZE 91K JAMBS INTO POSITION AND SECURE IN NEXT STEP BELOW



FRONT PANEL DOOR ASSEMBLY


NOTE: NUTS AND BOLTS (SUPPLIED) MAY BE USED INSTEAD OF POP RIVETS (SUPPLIED) BY SIMPLY ENLARGING THE HINGE HOLE SETS IN THE JAMB USING A 5/32" DRILL BIT




NOTE: The two holes required to connect the padbolt hasp for each door have not been pre-punched, to allow for proper alignment. position each hasp centrally over the padbolt shaft, and drill 3mm (0.18") holes and secure with screws

WALL PANEL CONSTRUCTION







FIT 4x FAST001 SCREW
AT EACH CORNER



SIDE WALL PANEL CHANNELS FIT
INTO THE NOTCHED FRONT AND
REAR WALL PANEL CHANNELS



LID PANEL INSTALLATION




- USE THE 3mm DRILL BIT TO DRILL 1x HOLE THROUGH THE 88Z LIP AS ILLUSTRATED
- DRILL ANOTHER HOLE THROUGH THE OPPOSITE END OF THE OTHER 88Z LIP AS ILLUSTRATED
- FIT THE 88Z LIP TO THE FRONT OF THE 61G CHANNEL USING 1x SCREW ONLY
- FIT THE OTHER 88Z LIP TO THE FRONT OF THE OPPOSITE 61G CHANNEL USING 1x SCREW ONLY
- THE 88Z LIPS ARE NOW ABLE TO PIVOT UP AND DOWN TO WORK AS PROPS FOR THE LID


FINAL CONSTRUCTION

AFTER FINAL ALIGNMENT AND ANCHORING HAS BEEN COMPLETED. CLOSE THE LID AND EXTEND THE LID PADBOLT UNTIL IT CONTACTS THE FRONT CHANNEL. MARK THIS CENTREPOINT AND DRILL A 10MM HOLE.


TIP: IT'S EASIER TO DRILL A 13/32" HOLE IN METAL WHEN A SMALL DRILL BIT IS USED FIRST.



ANCHORING OF SHED



INSIDE SHED




FIT 1x FAST007 HASP ON THE INSIDE OF 54R WHERE THE FAST006 PADBOLT ALIGNS

LIFT LID UP AND FIT FAST073 CHAIN TO 61G CHANNELS AND 91L JAMBS USING FAST014 SCREWS

TIP - LIFT LID TO HIGHEST PREFERRED OPEN POSITION AND FIT CHAIN TAUGHT

- EACH ANCHOR CONSISTS OF ONE NUT, BOLT, DYNABOLT AND STEEL ANGLE
- DRILL A 13/32" HOLE INTO THE WALL SHEET
- DRILL A 13/32" HOLE INTO THE CONCRETE
- POSITION THE STEEL ANGLE
- PLACE THE DYNABOLT INTO THE CONCRETE HOLE & TIGHTEN
- SECURE THE STEEL ANGLE TO THE WALL SHEET USING THE REMAINING NUT & BOLT
- REPEAT FOR EACH ANCHOR LOCATION



EXPORT PRODUCT WARRANTY AGAINST DEFECTS

Congratulations on your purchase of an ABSCO SHED

ABSCO SHEDS, including garden sheds, garden beds, aviaries, storage units, garages, awnings and carports are made using high quality Australian made steel.

We are pleased to advise we warrant that the steel coating will not rust, crack, flake peel or blister for 12 years from date of purchase.

This warranty does not apply to surface deterioration of panels caused by 'Swarf' (Tiny particles of steel debris left from cutting, grinding or drilling operations) that has not been removed after building construction, or as a result of contact with damp soil, chemicals, fertilisers or other corrosive substances.

This warranty covers any Absco product used for normal domestic use and installed in accordance with the installation instructions.

This warranty does NOT cover Damage caused by storms, wind, rain, snow or poor foundations.

This warranty does NOT cover ABSCO products installed in severe coastal, industrial or other highly corrosive environments. The warranty does not cover fasteners (screws, nuts, bolts, rivets, hasps or sliding padbolts).

The warranty is limited to replacement and delivery of components and does not include any labour or installation costs. The benefits given by the warranty are in addition to your other rights and remedies under a law in relation to the goods or services to which the warranty relates.

In the unlikely event a warranty claim is made, it must be supported by photographic evidence and details of the defect, including component part numbers, together with proof of purchase documentation (or on-line registration of purchase) and forwarded to the address below. Upon receipt of the warranty claim, the Customer Service Manager will contact you within three business days to advise you of the assessment outcome of the claim, which may include your expenses incurred in making the claim.

THE CUSTOMER SERVICE MANAGER, ABSCO SHEDS, PO BOX 119 ACACIA RIDGE QLD AUSTRALIA 4110

PHONE: +61 1800 029701 EMAIL: warranty@absco.com.au

Issued 16 July 2019