
## **Tips on Using This Product**

## Check the label.

All Gardner product labels include application instructions. When in doubt, check the label, and read the label directions.



## Check the data sheet.

Many of our products also have Data Sheets that you can find on this web site. Like the labels, the Data Sheets include information of surface preparation, application, cleanup and safety issues.

Click the MSDS & Data Sheet button on any page on our web site.

TIPS FOR PROFESSIONAL RESULTS: Apply during the summer, in the morning hours of a clear warm day. Temperatures should be a minimum of 65°F and rising, but not above 90°F. While product can be applied during other times, these are the optimum ranges that provide superior results. Also, apply brush strokes perpendicular to the street entrance, this hides application imperfections. If possible, use pails containing the same batch code stamp on the top of the lid. Remember to mix all buckets to a uniform consistency, and when using multiple buckets, blend the end of one bucket with the beginning of the next to prevent shade variances. Do not apply if rain or heavy dew is expected within 24 hours. Allow to cure 24-36 hours before vehicle traffic.

APPLICATION: Mix well. Apply with brush/squeegee applicator. If pavement gets hotter than 85°, mist with water to cool surface so sealer does not dry too fast. However, do not allow water to puddle. Apply sealer in thin coats, as two thinner layers adhere better than one thick one. Do not apply to steeply sloped surfaces, 20° incline or more, as this may present a slip hazard. If slope is in question, test small area first before applying to entire area. Note: newly paved surfaces must cure at least 12 months before applying sealer.

COVERAGE RATE: Coverage rates vary depending upon the condition of the existing surface. A brush and/or squeegee works best, allowing the sealer to penetrate the driveway surface. Working in a small area at a time apply thin coat, brushing away any excess as you seal. Use a cross pattern of application to insure all voids are filled and sealed. Driveway must cure approx. 2-4 hours for foot traffic and 24-48 hours for vehicle traffic. Humid or cloudy conditions may prolong curing time. Two thin coats are strongly recommended. Thick coats will result in uneven coverage, tracking and drying problems. Apply second coat perpendicular to the first, after the first coat has cured (approx. 3-6 hours) Approximate coverage for driveways in GOOD CONDITION: 400 sq. ft./5 gal. pail; AVERAGE CONDITION: 350 sq. ft./5 gal. pail.

CLEANUP: Soap & water when wet, or orange citrus cleaner when dry.

