

How To Assemble Your Rocking Chair (REV. 12/2016)








TOOLS NEEDED: Philips screwdriver, power drill optional

CAUTION: When assembling chair, **DO NOT** completely tighten the bolts and nuts until all the parts & holes are properly aligned.

- This chair is not recommended for weight of more than 250lbs.
- Care should be taken to avoid tipping while seated.
- This chair is designed for use on level ground only. Do not use on unlevel ground.
- To avoid harm or injury - do not sit on arms.
- Product is for residential use only - not meant for commercial use.







PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, make sure you have the following parts:

| No. | Description | Qty | Sketch | No. | Description | Qty | Sketch |
|-----|-------------|-----|---|-----|-------------|-----|---|
| A | Seat | 1 |  | E | Left Arm | 1 |  |
| B | Front Frame | 1 |  | F | Right Arm | 1 |  |
| C | Back | 1 |  | G | Runner | 2 |  |
| D | Rail | 2 |  | | | | |


HARDWARE LIST

When unpacking, please be careful not to discard any hardware with the packaging. Before continuing, make sure you have the following hardware:

| No. | Description | Qty | Sketch | No. | Description | Qty | Sketch |
|-----|---------------|-----|--|-----|------------------------|-----|---|
| I | Bolt | 4 |  | L | Long Screw Φ4x45mm | 10 |  |
| J | Spring Washer | 4 |  | M | Size:2 Hexagon Head | 2 |  |
| K | Allen Wrench | 1 |  | N | Allen Wrench | 1 |  |


Step 1:

Attach Seat (A) to the Back (C) with 2 bolts (I) & 2 Spring Washers (J) by using the Allen Wrench (N).



Step 2:

Put the 2 Rails (D) & the Front Frame (B) to the corresponding place, connect 2 Rails (D) & the Front Frame (B) with 4 Screws (L) then tighten with 2 Bolts (I) and 2 Spring Washers (J) by using the Allen Wrench (N).



Step 3:

1. Attach the Left & Right Arms (E, F) as pictured below. With a screwdriver, tighten the arms to the Back (C) with 2 Hexagon Heads (M) & to the Front Frame (B) with 2 Long Screws (L).

2. Attach the Runners (G) to the Back (C) & to the Front Frame (B) with 4 Long Screws (L) and a screwdriver.

