



## 20 or 30 AMPERE RECEPTACLE WIRING INSTRUCTIONS

**WARNING:** To prevent electrocution, make sure power is off and cannot be turned back on while installing receptacle.

-A qualified electrician must install receptacles.

-Failure to comply with the following instructions could cause an electrical failure or fire.

1. Make sure the receptacle has the proper electrical rating for the system on which it is being installed.
2. Wire size and type must comply with appropriate local electrical codes. The receptacle is designed for #14 through #8 AWG
3. Strip the wire insulation 9/16" per the strip gauge on the back of the receptacle.
4. Use copper wire only and make sure the wire is clean and a bright copper color.
5. Do not solder the ends of the wire.
6. Fully insert each wire under the clamp of the appropriate wire terminal. Make certain there is wire insulation under any terminal clamp and tighten the terminal screw to 20 inch/pounds torque.

### DO YOU STILL HAVE QUESTIONS?

Email , call or text our  
Customer Service Dept.

**Direct:** (414) 434-2220

**Text:** (414) 323-3240

info@acconnectors.com

[www.ACWORKS.com](http://www.ACWORKS.com)

20 AMPERE LOCKING RECEPTACLE		
<p><b>L5-20</b></p>	<p><b>L6-20</b></p>	<p><b>L14-20</b></p>
<p><b>L15-20</b></p>	<p><b>L16-20</b></p>	<p>NOT AN AVAILABLE AC WORKS™ PRODUCT</p> <p><b>L21-20</b></p>
30 AMPERE LOCKING RECEPTACLE		
<p><b>L5-30</b></p>	<p><b>L6-30</b></p>	<p><b>L14-30</b></p>
<p><b>L15-30</b></p>	<p><b>L16-30</b></p>	<p>NOT AN AVAILABLE AC WORKS™ PRODUCT</p> <p><b>L21-30</b></p>