


HOME DECORATORS *collection*

BF-24661 MSL CRAFT TABLE 31"Hx54"W

ASSEMBLY INSTRUCTIONS













Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware and compare with parts list to ensure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department. For efficient and speedy service please indicate the model number and code letter of part(s) needed

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST


<p>A</p>  <p>TOP PANEL-1PC</p>	<p>B</p>  <p>LEFT SIDE PANEL-1PC</p>	<p>C</p>  <p>RIGHT SIDE PANEL-1PC</p>
<p>D</p>  <p>BOTTOM PANEL-1PC</p>	<p>E</p>  <p>BACK PANEL-1PC</p>	<p>F</p>  <p>ACROSS BATTEN-1PC</p>
<p>G</p>  <p>FRONT PANEL-1PC</p>	<p>H</p>  <p>STAND PANEL-1PC</p>	<p>I</p>  <p>LEFT DRAWER PANEL FRONT-1PC</p>
<p>J</p>  <p>RIGHT DRAWER PANEL FRONT-1PC</p>	<p>K</p>  <p>LEFT DRAWER SIDE PANEL -2PCS</p>	<p>L</p>  <p>RIGHT DRAWER SIDE PANEL -2PCS</p>

M




DRAWER BOTTOM PANEL-2PCS

N



DRAWER BACK PANEL-2PCS

O



DRAWER SUPPORT PANEL-2PCS

P



CAM-BOLTS-8PCS

Q




CAM-LOCKS-8PCS

R



CAM-TOOL-1PC

S




FEET-4PCS

T




SCREWS-10PCS

U




SCREWS-18PCS

V




SCREWS-24PCS

W



SCREWS-30PCS

X



SCREWS-2PCS

Y




ALLEN WRENCH-1PC

Z




KNOB-2PCS

A1




DOWEL-2PCS

B1



OUTER SLIDER-4PCS

C1




INNER SLIDE-4PCS

D1




SCREWS-2PCS

E1




LEFT PANEL-1PC

F1




RIGHT PANEL-1PC

G1



SCREWS-6PCS


H1



WRENCH-1PC



NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE.

HOW TO SEPARATE GLIDES






PRIOR TO ASSEMBLY, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDE

NOTE: • UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1) . ASSEMBLE THE BACK/BOTTOM PANEL (E/D) .

- ATTACH BACK PANEL (E) USING 4 SCREWS (W) .




2) . ASSEMBLE THE FRONT/STAND PANEL (G/H) .

- ROTATE THE 2 CAM-BOLTS (P) INTO HOLES IN BOTTOM PANEL (D) .
- PLACE THE CAM-BOLTS (P) INTO HOLES IN STAND PANEL (H) AND USING 2 CAM-LOCKS (Q) .
- ATTACH FRONT PANEL (G) TO BOTTOM PANEL (D) USING 4 SCREWS (W) .




3) . ASSEMBLE THE OUTER SLIDER(B1) .

- ATTACH OUTER SLIDERS(B1) TO FRONT/STAND PANEL (G/H) USING 6 SCREWS(G1) .




4) . ASSEMBLE THE SIDE PANEL (B/C) .

- INSERT THE 2 DOWEL (A1) INTO HOLES IN SIDE PANEL (B/C) .
- ROTATE THE 2 SCREWS (D1) INTO HOLES IN ACROSS BATTEM (F) .
- ATTACH THE BACK/BOTTOM/Front PANEL (E/D/G) TO SIDE PANEL (B/C) USING 14 SCREWS (W) .
- ROTATE THE 4 FEET (S) INTO HOLES IN SIDE PANEL (B/C) .




5) . ASSEMBLE THE TOP PANEL (A) .

- ROTATE THE 6 CAM-BOLTS(P) INTO HOLES IN TOP PANEL (A) .
- PLACE THE CAM-BOLTS(P) INTO HOLES IN SIDE/STAND PANEL (H/B/C) AND USING 6 CAM-LOCKS(Q) .
- ROTATE THE 8 SCREWS(W) INTO HOLES IN SIDE/BACK PANEL (E/B/C) .




6) . ASSEMBLE THE SCREWS (T) .

- ROTATE THE 4 SCREWS(I1) INTO HOLES IN FRONT PANEL (G) .




7) . ASSEMBLE THE PANEL(E1/F1) .

- ATTACH PANEL(E1/F1) TO SIDE PANEL(B/C) USING 6 SCREWS(T) .




8) . ASSEMBLE THE OUTER SLIDER(B1) .

- ATTACH THE 2 OUTER SLIDER(B1) TO PANEL(E1/F1) USING 6 SCREWS(U) .




9) .ASSEMBLE THE LEFT DRAWERS.

- ATTACH DRAWER PANEL SIDE(K/L) USING 4 SCREWS(V).
- ATTACH THE KNOB(Z) TO DRAWER PANEL FRONT(I) USING SCREWS(X).
- INSERT THE DRAWER BOTTOM PANEL(M) INTO SLOTS IN DRAWER PANEL SIDE(K/L).
- ATTACH DRAWER PANEL BACK(N) TO BETWEEN SIDE DRAWER PANEL(K/L) USING 4 SCREWS(V).
- ATTACH DRAWER SUPPORT PANEL(O) TO BOTTOM DRAWER(M) USING 4 SCREWS(V).
- ATTACH THE 2 INNER SLIDE(C1) TO DRAWER PANEL SIDE(K/L) USING 6 SCREW(U).



10) .ASSEMBLE THE RIGHT DRAWERS.

- ATTACH DRAWER PANEL SIDE(K/L) USING 4 SCREWS(V).
- ATTACH THE KNOB(Z) TO DRAWER PANEL FRONT(J) USING SCREWS(X).
- INSERT THE DRAWER BOTTOM PANEL(M) INTO SLOTS IN DRAWER PANEL SIDE(K/L).
- ATTACH DRAWER PANEL BACK(N) TO BETWEEN SIDE DRAWER PANEL(K/L) USING 4 SCREWS(V).
- ATTACH DRAWER SUPPORT PANEL(O) TO BOTTOM DRAWER(M) USING 4 SCREWS(V).
- ATTACH THE 2 INNER SLIDE(C1) TO DRAWER PANEL SIDE(K/L) USING 6 SCREW(U).



11) .ASSEMBLE THE DRAWER.

- INSERT 2 DRAWERS INTO THE SLIDERS.

