Installation




Cleaning the air hose

- $\hfill\square$ A 3/8" air hose is required, with a maximum length of 25 ft.
- Clean the air hose of accumulated dust and moisture before connecting it to the air supply.

Ø

NOTE: If a longer air hose is required, connect a 1/2" air hose to the 3/8" air hose to ensure the tool has the necessary air supply.



2 Connecting to the air supply

- Always use clean dry air. Excessive moisture and dirt will greatly reduce the life of any air motor. We recommend the installation of an in-line filter-regulator as close to the tool as possible.
- Ensure all hoses and fittings are the correct size and secured tightly.

Recommended Air Line Set-Up	
Part	Description
Α	Dual Action Sander
В	Quick Plug
C	Quick Coupler
D	Air Hose
E	In-line Filter
F	Air Compressor

