
Important safety instructions

OWNER'S MANUAL

AND **INSTALLATION INSTUCTION** Ceiling Fans MODEL: FC140-BAA



READ AND SAVE THESE INSTRUCTIONS

Attention: Pictures in the IM are for reference only

1.WARNING - To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Solid-State Speed Control Device."

2.WARNING - To Reduce The Risk Of Personal Injury, Do Not Bend The Blade Brackets When Installing The Brackets, Balancing The Blades, Or Cleaning The Fan. Do Not Insert Foreign Objects In Between Rotating Fan Blades."

3.WARNING – TO REDUCE THE RISK OF FIRE. ELECTRIC SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING: a) Use this unit only in the manner intended by the manufacturer. If

you have questions, contact the manufacturer.

b) Before servicing or cleaning unit, switch power off at service panel and lock the service disconnecting means to prevent power from being switched on accidentally. When the service disconnecting means cannot be locked, securely fasten a prominent warning device, such as a tag, to the service pane

c) Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.

d) Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) of fuel burning equipment to prevent back drafting. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society for Heating, Refrigeration and Air Conditioning Engineers (ASHRAE), and the local code authorities

e) When cutting or drilling into wall or ceiling, do not damage electrical wiring and other hidden utilities.


4.WARNING - To Reduce The Risk Of Fire, Electric Shock, Or Personal Injury, Mount Directly To A Structural Framing Member

5.CAUTION- To Reduce The Risk Of Injury To Persons, Install Fan So That The Blade Is At Least 3.05 Meters (10 Feet) Above The Floor.

INSTALLATION INSTRUCTIONS - CEILING FAN NOTICE: To ensure the success of this installation, be sure to read the instructions and review the diagram thoroughly before beginning IMPORTANT SAFETY NOTICĚ Installation shall be carried out in accordance with the National Electrical Code (ANSI/NFPA 70), Canadian Electrical Code and local

WARNING – Make sure power is off before attempting installation.

CAUTION- To Reduce The Risk Of Injury To Persons, Install Fan So That The Blade Is At Least 3.05 Meters (10 Feet) Above The Floor.



NOTICE: The downrod cannot change length.

1. Install the ceiling fan hook (Figure 1) directly to building structure by using the two screws provided. 2. Release six M6 blade screws on the fan head, then fix the fan blades by fastening screws (Figure 2). 3. Hang the ceiling fan onto the hanger hook fixed on the building structurer(Fig. 3).

4. Install the wall-mounted controller onto the wall type outlet box (Fig.

5. Connect circuit according to circuit diagram. To be ensure the controller is connected in the line circuit. 6. After completing connection of circuit, check all fixing screws are fastened well in order to ensure the ceiling fan fixed well on the building structurer.




Fig.1





Fig.3

INSTALLATION INSTRUCTIONS









Fig.4







MAINTENANCE INSTRUCTION

The fan requires little maintenance. Do not try to fix it by yourself. Refer it to qualified service personnel if service is needed.

- . Before cleaning and assembling, fan must be switch power off.
- 2. To ensure adequate air circulation to the motor, keep vents at the rear of the motor free of dust. Do not disassemble the fan to remove dust.
- 3. Please wipe the exterior parts with a soft cloth soaking a mild detergent
- 4. Do not use any abrasive detergent or solvents to avoid scratching the surface.

Do not use any of the following as a cleaner: gasoline, thinner.

5. Do not allow water or any other liquid into the motor housing or interior parts.

CLEANING

- . Be sure switch power off from the electrical supply source before cleaning.
- 2. Plastic parts should be cleaned with a soft cloth moisten with mild soap. Thoroughly remove soap film with dry cloth.

DISPOSAL: Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

Questions, problems, missing parts? Before returning to the store call Home Depot Customer Service

8 a.m.- 7p.m,EST,Monday-Friday,9 a.m.- 6 p.m,EST Saturday 1-877-527-0313

HOMEDEPOT.COM