




# Best Barns USA Assembly Book

Revised September 19, 2017



the Millcreek

12'x 16'

**Manufactured by Reynolds Building Systems, Inc.**

205 Arlington Drive      Greenville, PA 16125

This manual is copyrighted. Under the copyright laws, this manual may not be copied, in whole or in part, without consent from Reynolds Building Systems, Inc. © Copyright 2011

## IMPORTANT INFORMATION ABOUT YOUR SHED KIT

Download the most current instruction book at [www.barnkits.com](http://www.barnkits.com); use the "manuals" link on the menu bar and then select your building kit and size.

Thank you for purchasing our shed kit. Read the instructions before starting the assembly of the building. If you have any questions about assembling the kit, call 800-245-1577. Business hours (8:00-5:00 ET) Monday thru Friday. After business hours call 724-866-HELP (4357) or email to [help@barnkits.com](mailto:help@barnkits.com).

The material that is included in our kit is listed on the back page. The optional floor package, if purchased, will be supplied by a local lumber supplier.

Our kit does not include the shingles, the quantity needed is listed on the back page. The siding is primed. You will need to apply a finish coat using latex acrylic paint.

Some of the framing lumber was used in the shipping pallet. Unpack the material from the pallets. Unscrew the OSB panels and the 2x4s from the shipping pallet. The 2x4s will be used for wall bracing and to support the loft beams. The bit for the screws is packed in the hardware bag.

Most buildings are installed on a wood floor and the siding was designed to extend over the wood flooring. If the foundation is a concrete floor cut the siding flush with the bottom of the wall plate to prevent the concrete from contacting the siding.



Stacking the boards, according to size, will make them easier to find when needed. **Do Not** discard any material until your building is complete.

Before you begin construction, be sure to study this assembly manual. Also, obtain a building permit and check all pertinent building code regulations for your area.

Thank you for your purchase.

Bill & Linda Rinella, owners

To identify which edge we want you to use, we will refer to the edge as either the 'LAP' Edge or the Tongue Edge.



When measurements are given for a board length or width, it is from the longest side.

### Tool List

- |   |  |
|---|--|
| <input type="checkbox"/> Hammer & Hand Saw      | <input type="checkbox"/> Power Drill/screwdriver |
| <input type="checkbox"/> Framing Square & Level | <input type="checkbox"/> Measuring Tape          |
| <input type="checkbox"/> Power Circular Saw     | <input type="checkbox"/> 2-8' Step Ladders       |

**Always wear safety glasses when cutting or nailing!**


## Constructing Details for Deluxe Floor System

*Deluxe floors include 4x4 runners, standard floors do not*


Foundation size is 12'-0" x 16'-0". Check local building codes in your area, the construction may have to change. For a concrete slab, install sill sealer as a moisture barrier between the concrete and the wall plates. Foam sill sealer can be purchased at home centers in rolls 3-1/2" or wider.

1. Cut (2) two 2x4-8' boards into 2' long blocks. Butt the 4x4-8' timbers together to make 16' runners. Secure the 4x4s together with the 2' long 2x4 blocks and 16d galvanized nails.
2. Cut (2) two 2x4 joist headers to 16' - 0". Layout for 16" on center joist spacing. 'X' marks where floor joist will be placed.

2x4 Joist Header




3. Cut 2x4-12' floor joist to 11'-9". *Treated lumber may be thicker than 1-1/2". Take this into account when cutting the length of floor joists. Shorten joist measurements if necessary to obtain 12'-0" building width.*



It is important that the floor be level and square. Square the floor as follows: before nailing the flooring, measure the floor diagonally (corner to corner). Then measure the opposite corners; these measurements will be the same when the floor is square. Toenail frame to the 4x4 runners.

Install the flooring with 8d galvanized spiral floor nails spaced 8" apart


Material Description	Qty. & Size
2x4 Treated Blocking	2 pcs. 8'
2x4 Treated Floor Joists	13 pcs. 12'
2x4 Treated Joist Headers	2 pcs. 16'
4x4 Treated Runners	8 pcs. 8'
Flooring: 5/8" or 3/4"	6 pcs. 4x8
Galv. Spiral Floor Nails	3 lbs. 8d
Galvanized Deck Nails	3 lbs. 16d




Nail 2x4 joist headers and floor joist to 4x4 runners.

## Step 1 Assemble Loft Beams

1. Locate (2) two 36" long 2x6 boards with a notch on one end and a 2x6 board without a notch. Position these 2x6 boards on a flat surface as shown below.
2. Apply a coat of glue to the top surface using wood glue supplied in the kit.
3. Locate (2) two 72" long 2x6 boards with a notch on one end. Install these 2x6 boards over the bottom boards.




4. To provide additional strength, install 2-1/2" wood screws spaced 16" apart as shown below.



5. Repeat steps to assemble a second Loft Beam.


## Step 2 Assemble Gable Plates

1. Butt (2) two 72" long 2x4s together and secure them by nailing a 3-1/2" x 42-3/4" long plywood gusset across the top where they butt together. The gusset needs to be centered on the 2x4s (approximately 50-5/8" of the 2x4s will be exposed on each side of the gusset). Use wood glue and (2) two rows of (20) twenty 6d common nails to secure the gusset.




2. Repeat to assemble a second Gable Plate.

### Step 3 Assemble Trusses

 **Building Tip:** To aid in the assembly of the trusses, temporarily tack-nail or screw 2x4 blocks to the floor using short 2x4 packing blocks supplied in kit. This will ensure that all the trusses are assembled the same.

1. Position a Gable Plate (from **Step 2**) on the floor with the narrow edge side down. Use 2x4 blocks to hold the 2x4 plate straight.
2. Position (2) two truss halves (*2x4s connected with a metal plate*) with the short legs against the 2x4 Gable Plate Assembly. **DO NOT** attach the Gable Plate Assembly to the truss. It is temporarily used to help hold the 2x4 truss parts in place and will be attached in a later step.
3. Secure 2x4 blocks around the perimeter of truss to hold truss parts in place.




4. Nail a 31-3/4" long 2x3 block where the trusses meet at the top with 10d coated sinker nails. Secure with a 32" wood gusset. Apply wood glue between the gusset and truss and nail with (25) twenty-five 6d common nails.
5. Turn the truss over and install a gusset to the other side of the truss.
6. Repeat this process to assemble (6) six more trusses.


## Step 4 Assemble Roof Gables


 **DO NOT** use trusses from Step 3 to assemble the roof gables.

1. Place (2) two truss halves together and secure the top with a 1"x4" barbed metal plate.
2. Nail a 31-3/4" long 2x3 board to the truss at the ridge with 10d coated sinkers.
3. Cut a 42-3/4" long 2x4 to fit and install in the center of the gable. Nail through gable plate and plywood gusset with (2) two 10d sinkers. Secure the top with a 1x4 barbed metal plate.
4. Butt (2) two 40-3/4" long 2x4s against the wood gusset. Secure the bottoms to the 2x4 gable plate by nailing through plate with (2) two 10d sinkers. Secure the tops with a barbed plate.
5. Install (2) two 30-3/4" long 2x4s with barbed plates and nails.
6. Nail truss leg to 12' Gable Plate with 10d sinkers.



7. Position 2nd gable plate and repeat steps to assemble the front roof gable. **Read note below:**

 *If you want the loft doors to open, repeat steps 1-6 substituting number step 3 with directions below:*




3. Install a 42-3/4" long 2x4 board in the opening 32" from top of wood gusset. Secure with 1"x4" metal barbed plates.




## Step 5A Apply Siding to Rear Roof Gable

1. Remove 2x4 blocks and turn gable frame over.
2. Install pre-cut siding on rear gable. First piece will have a 'Tongue' edge. Start from left and install siding extending 3/4" below gable plate. Siding must not extend above the top frame. Use 8d galvanized box nails along the gable plate and 6d galvanized box nails on studs and truss frame. Space nails 8" apart.




## Step 5B Apply Siding to Front Roof Gable

1. Install siding on right working left. Lay out the first (2) two pieces of siding on frame. **Important: Do not nail to frame if loft doors are to open.** Mark and cut so siding is flush with top and right side of loft door opening. Cut to bottom of siding below gable plate. Nail first two pieces of siding to frame. Lay out next siding panel, **do not nail if loft doors are to open**, and repeat cut for left side door opening. Nail last two pieces of siding to frame.
2. Install (2) two 61" long 2x3 boards with blue marking at one end. Install this end at the top of **front gable** only. Ensure 2x3 is flush with gable frame. Use 10d sinkers.
3. Install (2) two 42-1/2" long 2x3s. Use 10d sinkers.




## Step 6 Assemble Sidewalls


1. Position (2) two 2x4-72" boards together and indicate with 'X' marks, where the wall studs will be located.



2. Install (4) four 80-1/4" long wall studs between the wall plates. Use (2) two 10d coated sinkers at each end of stud.



3. Repeat process to assemble (3) three more 72" wall frames.
4. Install (3) three 80-1/4" wall studs between (2) two 48" long 2x4s boards. Install the stud in the center of the wall frame.





5. Repeat to assemble another 4' wall section.




## Step 6 Assemble Sidewalls (continued)

6. Position a 48" wide wall frame between (2) two 72" wall frames as shown below. Nail frames together with (5) five 10d coated sinker nails, alternating sides.
7. Square wall frame. *Measure diagonally (corner to corner); the measurements will be the same when the wall is square.*



 Cut the siding flush with the bottom plate if installing the building on a cement slab.



8. Install the first siding panel with the 'LAP edge' flush the end of the wall and extending 3/4" below the bottom plate. Use 8d galvanized box nails spaced 8" apart.
9. Install (2) two more siding panels. You can install the last siding panel now or after the walls are erected so the panel will be easier to handle.




10. Repeat to assemble the another sidewall.

## Step 7 Assemble Back Wall

1. Position (4) four 68-1/2" 2x4 boards together and indicate with 'X' marks where the wall studs will be located. Mark the ends that will butt together with the letters 'A' and 'B'.
2. Install (8) eight 80-1/4" long wall studs, between the wall plates, over the 'X' marks and where the plates meet. Use (2) two 10d coated sinkers at each end of a stud. Nail wall sections together using (5) five 10d coated sinker nails, alternating each side of the studs.




3. Square wall frame. *Measure diagonally (corner to corner); the measurements will be the same when the wall is square.*
4. Install the 1st siding panel with the 'LAP' edge extending 3-1/2" past the wall frame. Use 8d galvanized box nails spaced 8" apart. The bottom will extend 3/4" below the bottom plate, or trim flush for cement slab.
5. Install the other siding panels. Cut the last panel to extend 3-1/2" beyond the wall frame.



## Step 8 Assemble Door Header


Assemble door header using (2) two 75" long 2x6 boards and a 75" OSB filler panel. Apply wood glue between OSB and boards. Nail header together with 10d coated sinkers. Use (12) twelve nails on each side.



## Step 9A Assemble Bottom Wall Plate (doors offset)


 If you want the barn doors in the center of the front wall, go to **Step 9B**.

1. Butt (2) two 68-1/2" boards together to make bottom wall plate. Secure bottom plate with a 2x4-6' board (used as door spacer) installed 56-1/2" from the end of the 2x4 wall plate. Secure with (4) four 2-1/2" wood screws.
2. Mark locations for the wall studs with 'X' marks.
3. Go to **Step 10A**.



## Step 9B Assemble Bottom Wall Plate (doors centered)

1. Butt (2) two 68-1/2" boards together. Center a 2x4-6' board (used as door spacer) on top and screw the boards together using (4) four 2-1/2" wood screws.
2. Mark stud spacing as shown below.




3. Go to **Step 10B**.

## Step 10A Assemble Front Wall (doors offset)

1. Gather the material listed below to assemble the door wall.
2. Install (4) four 80-1/4" wall studs over the 'X' marks using 10d coated sinker nails.
3. Install the wall studs with the door jacks on each side of the door spacer.
4. Install door header on the door jacks.


Material List	
2	68-1/2" Wall Plates
4	80-1/4" Wall Studs
2	80-1/4" Wall Studs w/ door jacks attached
1	Door Header from <b>Step 8</b>
1	Bottom Plate from <b>Step 9A</b>

\* Check measurements. They should be the same or the door opening will not be square!



 **To install doors offset to the left, flip wall before applying the siding.**

5. Install a 12" and a full width siding panel on the left corner (right corner if installing door on left side). The cut edge on the 12" siding should be flush with the left side of the door opening and extend 3-1/2" past the frame. **Do Not** nail the 'LAP' edge until the other siding is applied. Position the full width siding panel and nail along the 'LAP' edge of the 12" wide panel.
6. Install (2) two 7-3/4" high pre-cut siding panels over the door opening. The siding will extend 3/4" below the door header.
7. Install a 12-3/4" wide siding panel on the end of the wall frame. The siding will extend 3-1/2" beyond




*Optional windows can be installed now or later.*

## Step 10B Assemble Front Wall (doors centered)


1. Gather the material listed below to assemble the door wall.
2. Install (4) four 80-1/4" wall studs over the 'X' marks using 10d coated sinker nails.
3. Install the wall studs with the door jacks on each side of the door spacer.
4. Install door header on the door jacks.

Material List	
2	68-1/2" Wall Plates
4	80-1/4" Wall Studs
2	80-1/4" Wall Studs w/ door jacks attached
1	Door Header from <b>Step 8</b>
1	Bottom Plate from <b>Step 9B</b>




\* Check measurements. They should be the same or the door opening will not be square!


5. Locate a 12" siding panel that has a 'LAP' edge. Position the 'cut' edge flush with the left side of the door opening. **Do Not** nail the 'LAP' edge until the other siding is applied.
6. Cut a full width siding panel in half lengthways. Select the siding with the 'tongue' edge and install this siding panel at the left end of the wall frame.
7. Install (2) two 7-3/4" pre-cut siding panels over the door opening, flush with the top plate.
8. Install a 12-3/4" siding panel with the 'cut' edge flush with the side of the door opening.
9. Install the last siding panel. It will extend 3-1/2" beyond the 2x4 wall frame.



## Step 11 Set Walls

 **Tip:** Use the 2x4s from the shipping pallet as braces to hold the walls straight.


1. Set the back wall panel between the sidewalls. Secure wall panels together at the corners using (5) five 10d coated sinker nails per corner. Nail wall panels to the floor through the bottom plate using 10d coated sinkers; (2) two nails per stud opening.
2. Install the front wall frame between the sidewalls.
3. Install the last siding panel on the sidewalls. Nail along the siding edge where the sidewall siding panels overlap.



5. Unscrew and remove the 2x4 door spacer (this will be used later). Cut and remove the bottom 2x4 in the door opening.

## Step 12 Layout Loft Joist Spacing on 2x6 Beam

Layout both beams for the spacing of the loft floor joists.  
The 'X' marks where the floor joist will be placed.







## Step 13 Install 2x6 Loft Beams

1. Cut (4) four 2x4 boards taken from one of the shipping pallets to a length of 76-1/4".
2. Install the front 2x6 beam to the side of the double studs facing the front of the building. Place the notch under the top plate and support the beam with one of the 76-1/4" long 2x4s. Further secure the beam with a 2-1/2" wood screws through the top of the wall plate.

3. Install the rear beam in the same manner. Install the 2x6 beam to the side of the double studs facing the back of the building.




**Important:** When installed properly the 'X' marks will be facing the front wall on the front beam and the back wall on the back beam. The beams will be 51" apart.





## Step 14 Install Loft Floor Joists

1. Install (2) two 68-1/2" long 2x4s on the back wall to support the floor joist. Install the 2x4s 3-1/2" below the top of the wall plate. Secure to wall studs with 10d sinkers, 2 nails per stud.

68-1/2" Long 2x4




2. Install 64" long 2x4 floor joist. Secure one end to the loft beam using 2x4 hangers over 'X' marks. Use 10d sinker coated nails. Toenail other end on top of the 68-1/2" long 2x4s installed on the wall.



3. Repeat steps for the front loft area.

## Step 15 Install Loft Flooring


1. Install 7/16" OSB loft flooring on back loft floor joists. Loft flooring is flush with outside of top wall plate. Use 7d sinker nails spaced 8" apart. *See layout pattern below:*




2. Repeat to install loft flooring at the front of the building.
3. Cut 3-1/2" x 56" long floor fillers to size and fit between the loft flooring.

## Step 16 Install Wall Trim

1. Install (2) two 84-1/2" long 1x4 corner trim boards on the back wall, flush with the siding on the sidewall. Use 8d galvanized box nails spaced 12" apart.
2. Cut to fit and install (2) two 1x4-72" trim boards across the top of the back wall. Install the 1x4 boards flush with the top of the loft flooring. *See diagram below.*
3. Repeat for front wall trim.




## Step 17 Set Rear and Front Gables



1. Install the rear gable on the rear wall. The siding on the gable must extend over the 1x4 trim board, not behind it. *See detail 'D' below.* Nail bottom gable to loft flooring. Use 10d sinker nails spaced evenly in stud openings.

**WARNING:** The gable ends are heavy and awkward. You'll need helpers to lift and set gables in place.

2. Install (2) two 61" long 1x4 gable trim flush with the top edge of the gable. Install the ends with blue marks together. Install trim with 8d galvanized nails spaced 12" apart.
3. Install (2) two 42-1/2" long 1x4 gable trim flush with the side edge of the gable.
4. Install the front gable. Do Not apply trim.



**DETAIL 'D'**


1x4 Trim

1x4 Trim

Bottom Edge of Gable Siding  
Overlaps Top Wall Trim; nail  
with 8d galvanized box nails.


## Step 18 Install 2x4 Truss Plates

1. Install a 48" long 2x4 truss plate against the rear gable and flush with outside edge of wall plate. Install a 72" long 2x4 truss plate. Cut another 72" tie plate to size and install. Use 10d coated sinker nails spaced 16".
2. Repeat to install truss plates on the opposite side.



3. Layout the truss spacing. Measure from the inside face of the 2x4 gable plate to mark the location of the first truss. The last truss space will be more than 24".



**Important:** When marking the opposite wall, place the 'X' mark on the same side of the line so your trusses are parallel when they are installed.



## Step 19 Install Trusses & Soffit Boards

1. Place trusses over the 'X' marks and secure trusses to 2x4 truss plate using 2x4 hangers and 10d coated sinker nails.
2. Locate 65-1/4" long soffit boards that have a beveled edge. Install one of these boards flush with the top of the siding and butting against the rear gable trim. Secure soffit boards to the top wall plate with 3" long screws spaced 8" apart. Install the last soffit boards to fit behind 2x3 boards on the front gable.

Metal Truss Hanger



Soffit Board Flush With Siding


## Step 20 Install Roof Sheathing

Straight Edge

1. Install a 42" x 72" OSB roof panel flush with the face of the rear gable trim. Use a straight edge to align the top of the sheathing with the top of the truss. Continue adding sheathing following the layout on the next page. Use 7d coated sinkers, spaced 6" apart.
2. Repeat step for opposite side.




To prevent the nails from protruding through the bottom of the soffit board, do not nail at an angle when nailing roof sheathing to the soffit boards.





## Step 20 Install Roof Sheathing (continued)

3. Install roof sheathing on the upper roof trusses. Insert (2) two pyclicks onto roof sheathing between every truss on the top row. The top row of roof sheathing will be about 1" below the ridge to allow for ventilation. Use 7d coated sinker nails spaced 6" apart.
4. Repeat for the opposite side.
5. Install 80" long 1x4 trim boards on the corners of the sidewalls using 8d galvanized nails spaced 12" apart.




## Install Roofing — Not Supplied in Kit

**After completing Step 21 next**, install metal roof edging on perimeter of the roof area. If you are not installing shingles at this time, you can purchase felt paper to protect the sheathing. Install the felt paper before you install the metal roof edge.


Install shingles according to the instructions on the wrapper. Additional information and tutorials can be found on various online sources.

**Building Tip:** Install ridge vent in lieu of shingle caps. Ridge vent provides ideal ventilation, preventing heat and moisture build-up from damaging your building or its contents.




*Optional ridge vent provides ideal ventilation.*

## Step 21 Install Front Gable Overhang




3. Install (2) two 1x4-61" gable trim boards, *with the ends marked with a blue line* together at the ridge.  
Install trim boards with 8d galvanized box nails spaced 12" apart.


4. Install (2) two 43-1/2" long 1x4 trim boards on the sides.
5. Cut to fit 7-1/2" wide soffit panels under the overhang. Use 6d galvanized nails.
6. Install 35-3/4" long 1x3 trim boards flush with each side of the loft door opening. Install a 50" long trim board across the top. *If door opening is cut out the siding will extend 3/4" below the top trim board.*
7. Install loft doors using 4" hinges and 1-1/4" long black screws. Install a 4" barrel bolt to the back of the right door using 1-1/4" black screws. Drill a hole for the round shaft to drop into.



## Step 22 Install Doors



1. Lay the left door with the trim facing up. The siding on the left door extends past the door trim. See detail below.
2. Install 5" hinges to the left side of the door frame. To position the hinge properly, hold the rectangular plate against the frame. Use 2" black screws.
3. Install hinges to the right side of the other door.
4. Install 76-3/4" long trim boards along each side of the door opening. Tack these boards with a couple nails; you may want to move the trim later when you install the doors.
5. Install the 81-3/4" board, *that has angle cuts on both ends*, over the door opening.




Before you fasten the hinges to the door trim, temporarily prop the doors in the opening. **Tip:** set the door stop on a piece of siding to help hold the door in place. Leave a space between the doors and the side trim to allow room for the doors to expand when they absorb moisture.

If your door opening is out of square, the space around the doors will not be even. You can reposition the side trim to make allowances for this. The side trim does not have to be flush with the frame of the door opening. You can move the trim in or out to make the door spacing equal.

Secure trim with 8d galvanized box nails spaced 12" apart.

Attach hinges to trim with 2" black screws.

Siding Extends Past Trim



6. Install a barrel bolt, on the lower back of the door with 1-1/4" black screws to secure this door in place when closed. Drill a hole for the round shaft to drop into.
7. Install another bolt at the top of the door.
8. Install door latch with screws provided.

## Millcreek 12' x 16' Barn kit Packing List

Qty.	Description	Size	Qty.	Description	Size	
<b>2x4 Framing</b>			<b>White Pine Trim</b>			
34	Wall Studs	80 1/4"	4	1x4 Gable Trim	61 "	
2	Wall Studs wuth Door Jacks	80 1/4"	4	1x4 Gable Trim	42 1/2"	
16	Gable & Wall Plates	72 "	4	1x4 Lower Wall Trim	72 "	
12	Wall Plates & Floor Joist Ledgers	68 1/2"	4	1x4 Corner Trim	84 1/2"	
10	Loft Floor Joist	64 "	4	1x4 Corner Trim	80 "	
6	Wall & Tie Plate Material	48 "	1	1x4 Door Trim	81 3/4"	
2	Gable Studs	42 3/4"	2	1x4 Door Trim	76 3/4"	
4	Gable Studs	40 3/4"	1	1x3 Loft Door Trim	50 "	
4	Gable Studs	30 3/4"	2	1x3 Loft Door Trim	35 3/4"	
<b>2x6 Framing</b>			<b>Pre-built Components</b>			
2	Door Header	75 "	18	Pre-built Truss Halves		
6	Beam Material (4 with notch)	72 "	6	3-1/2" x 65-1/4" Pre-built Soffit Boards		
4	Beam Material with notch	36 "	2	36" x 76" Pre-built Barn Doors		
<b>2x3 Framing</b>			2	21" x 35-1/2" Loft Door Frames		
4	Gable Extension <i>top</i>	61 "	<b>Hardware</b>			
4	Gable Extension <i>side</i>	42 1/2"	7	lb. 10d Sinkers	32 7/16" Plyclips	
2	Gable Extension Blocks	4 1/2"	7	lb. 8d Galv. Box	2 Bottle Glue	
9	Truss Ridge Blocks	31 3/4"	5	lb. 7d Sinkers	98 Black Screws	
<b>Miscellaneous Lumber</b>			3	lb. 6d Common	24 Truss Hangers	
10	24 Blocks for Truss Jig	10" to 12"	1	lb. 6d Galv. Box	1 Door Hasp	
1	OSB Door Header Filler	5-1/4" x 75"	2	4" Barrel Bolts	2 6" Barrel Bolts	
14	Wood Gussets for Trusses	9" x 32"	14	1x4 Drive-on Plate	160 Wood Screws	
2	7/16" Loft Floor Fillers	3-1/2" x 56"	6	4" Door Hinges	6 5" Door Hinges	
<b>Lower Wall Siding</b>		<b>Gable Siding &amp; Soffit</b>		2	3/4" Plywood Gable Nailer	3-1/2" x 42-3/4"
12	48" x 84"	4	<b>7/16" OSB Sheathing</b>			
2	12" x 84"	4	6	48" x 72"	2 48" x 36"	
2	7-3/4" x 36"	4	4	42" x 72"	4 48" x 48"	
		2	2	42" x 60"	4 22-1/2" x 72"	
		2	2	13" x 60"	4 13" x 72"	

Roof Material: 10 bundle shingles, 8 pcs. 10' metal roof edge, optional felt paper 1 roll