


# **USE AND CARE GUIDE**

#### 48 FT COMMERCIAL STRING LIGHT



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

**HAMPTONBAY.COM** 

## **Safety Information**

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

## READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- Do not use these products outdoors unless marked suitable for outdoor use.
- When products are used outdoor applications, connect the product to Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- Do not mount or place near gas or electric heaters, fireplace, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails. Install only using the mounting means provided.
- Do not let lamps rest on the supply cord or on any wires.
- Do not hang objects from the cord, wire, or light string.
- Do not use this product for other than its intended use.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper or any material not part of the product when in use.
- Read and follow all instructions that are on the product or provided with the product.

Connecting multiple sets:

Add the wattage of each light string together for a total of 1200 Watts or less.

### **DO NOT EXCEED 1200 WATTS**

When connecting multiple sets protect connection(s) from direct exposure to rain and water. Do not allow connection(s) to become wet.



## CAUTION: RISK OF ELECTRIC SHOCK

Do not use with extension cord near water or where water may accumulate.

Keep lamps at least 16 feet (4.88m) from pools and spas. Keep plugs and receptacles dry.

Do not submerse.



#### WARNING: RISK OF ELECTRIC SHOCK

Disconnect power at the source prior to wiring, re-lamping or servicing in any way. The light string kits are supplied with an attached three prong plug that will only fit into a three prong outlet. Do not alter the plug.

### SAVE THESE INSTRUCTIONS



#### **CAUTION:**

To reduce the risk of fire use only type S lamps, 11 watts maximum.



To reduce the risk of fire do not deliberately reposition either lampholder contact.

#### **CONNECTING MULTIPLE SETS**

Maximum Wattage	Number of String Lights
7.5 watts	6 sets
11 watts	4 sets
15 watts	3 sets
20 watts	2 sets
30 watts	1 set

## **DO NOT EXCEED 1200 WATTS**

## **MODEL NUMBER: 72123/HD**

The lighting string is rated at 120V, 60Hz, 264 Watts. It is provided with 24 lampholders and 11 Watts S Type lamps.

Before returning to your local Home Depot, please call our Customer Service team at 1-855-HD-HAMPTON or visit www.hamptonbay.com. Please reference your SKU (1003-438-988 48 FT COMMERCIAL STRING LIGHT).

## **Pre-Installation**

#### PLANNING INSTALLATION

Read all instructions before installation.



#### **IMPORTANT**

Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have occured during shipping. If there is a defect in the wire, do not attempt installation. Please call the Customer Service Team at 1-855-HD-HAMPTON.



**NOTE:** Support cable and hardware not included (sold separately).




**NOTE:** You may use bulbs of different wattages other than those included (sold separately). See chart below for details.

#### **CONNECTING MULTIPLE SETS**

Maximum Wattage	<b>Number of String Lights</b>
7.5 watts	6 sets
11 watts	4 sets
15 watts	3 sets
20 watts	2 sets
30 watts	1 set

## **DO NOT EXCEED 1200 WATTS**

## **PACKAGE CONTENT (parts are not to scale):**




Part	Description	Quantity
Α	48 FT Heavy-Duty String Light	1
В	S14, Medium Base (E26) 11W Incandescent Bulbs	36


## Installation

#### **INSTALLATION METHODS**

# Using a guide wire with S-hooks or temporary ties (not included)



# **2** Attached to a structure



## **Installation (continued)**

#### **RE-LAMPING STRING LIGHTS**

 $\triangle$ 

**WARNING: RISK OF ELECTRIC SHOCK!** 

Disconnect power at the source prior to re-lamping the string lights. For outdoor string lights, DO NOT re-lamp light strings during rain or when wet

- □ Re-lamp string lights only during dry and calm weather conditions.
- □ Unscrew existing lamps by lightly holding the socket in one hand and twisting the lamp counterclockwise. Lamps may be tight in the sockets. This is normal to prevent moisture from getting into the socket.
- □ Replace with medium base lamps. Screw bulbs into the sockets clockwise until the top of sockets form a tight seal around the bulbs and the bulbs make contact with the sockets. Do not exceed 1200 watts all sets combined. Suitable for Incandescent, CFL or LED lamps.

#### **MAINTENANCE**

Periodically clean the string light, check connections and ensure no additional weight has been added.

#### **TROUBLESHOOTING**

PROBLEM	POSSIBLE CAUSES	SOLUTION
The lights will not turn on.	The bulb is burned out.	Replace the light bulb.
	The power is off.	Ensure the power supply is turned on.
	There is a faulty switch.	Test or replace the switch.
	There is a faulty wire connection.	Check the wiring.
	The bulb is not making contact with the terminal.	Check position of terminal inside socket.
The fuse blows, or the circuit breaker trips, when the light is turned on.	There are crossed wires, or the power wire is grounding out.	Discontinue use of the light string. Contact a qualified electrician or call the Customer Care Services Team.
	The receptacle circuit is overloaded.	Connect to a different receptacle circuit.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

**READ AND FOLLOW ALL SAFETY INSTRUCTIONS** 

**SAVE THESE INSTRUCTIONS**