

# Always wear proper safety equipment such as gloves and eye protection.

## Supplied:

The Fix-A-Fence channel brace  
The Fix-A-Fence anchor section  
3 qty. 5/16 x 3 inch lag screws  
3 qty. #14 x 1 inch Tek screws  
1 qty. 5/8 x 1 inch bolt

## Tools Needed:


Ratchet or drill  
7/16 inch socket (wood)  
3/8 inch nut driver (metal)  
Post hole digger or shovel  
15/16" socket or adjustable wrench  
Wheelbarrow or 5 gallon bucket  
Level  
Measuring tape

- 1.) Remove red plug from anchor section (keep for future use if Channel Brace is ever removed). Bolt anchor section to channel brace using supplied 5/8" bolt and tighten firmly (see figure 1).
- 2.) Measure 8 inches out from the bottom edge of the damaged post (this marks the center of the hole to be dug).
- 3.) Using your mark, prepare a hole 18 inches deep and 6 inches in diameter. (See Figure 2)
- 4.) Place the assembled Fix-A-Fence into the hole, keeping the base against the bottom of the post. (See Figure 3)
- 5.) Mix the 60 lb. bag of concrete according to the manufacturers instructions.
- 6.) Fill the hole with concrete to the base of the channel brace. Maintain the center line of the Fix-A-Fence and the post. (See Figure 4)
- 7.) Plumb Fix-A-Fence with a level, keeping the base of The Fix-A-Fence against the bottom of the post. (See Figure 5)
- 8.) Allow concrete to set according to manufacturers instructions.
- 9.) Once the concrete has set, pull the fence post firmly against The Fix-A-Fence and install supplied lag screws starting at the top. No pre-drilling is needed. If attaching to a metal pole, use the supplied Tek screws (drill with 3/8 inch nut driver required)


## LEGEND

Channel Brace - - - - -

Anchor Section - - -



## You're done!



\*Lifetime guarantee on The Fix-A-Fence product only. \*\*In colder climates we recommend bellling the bottom of the hole. See illustration- 