

INSTALLATION INSTRUCTION

1. Select installation orientation: installing horizontal or vertical.



2. Using a level, draw a line on the wall for the Starter Plank.



3. With the Starter Plank (pre-cut 8" or 16" length) face down, apply one piece of tape to the left side in the center of the plank. Then apply two pieces to the right side overhanging the plank (See picture).




4. Line up the starter plank with your line on the wall. Stick the plank (pressing firmly) on the wall.




5. For the Next Plank, apply two pieces of tape to the right side overhanging the edge as you did on the Starter Plank.



6. Line up the vertical edges of the Starter plank and the Next plank. The Next Plank will cover the overhanging tape on the starter plank. No gap is required between boards. Press firmly to the wall.



7. Continue installing planks across the wall using the same method of two planks sharing two pieces of tape. Again, no gaps are necessary. Boards may touch on all sides.



8. When you come to the end of the row, use the pre-cut (8" or 16" length) Finish Plank with one piece of tape centered on the right side of the plank.



***Notes:** The pre-cut pieces allow for staggering seams. The 8" or 16" may be used as the Starter/Finish Plank. Alternating them creates a gorgeous wall design. They may also be used anywhere in a row to stagger the seams. You may cut full planks to desired lengths as well using a hand saw or power saw (fine tooth blade recommended).