



NOT JUST A PRODUCT...A SOLUTION. **EKENAMILLWORK.COM**

Urethane Gable Vents shine when it comes to looking like a real wood product without all the maintenance that can come with wood. They are moulded from beautiful designs, like wood products, and come to you factory primed and ready for your paint. These vents offer the least amount of airflow, but can vent ordering the functional option. Highly recommended for decorative applications.

Tools & Materials Needed

- Caulking gun
- Elastomeric adhesive caulk
- Sponge or clean cloth
- Putty knife
- Extra fine sandpaper
- Hammer & finishing nails (Nails must be long enough to penetrate the substrate at least 1/2")
- Jigsaw, keyhole saw, or pen-knife

Prior to Installation


- It is highly recommended that you paint/finish our gable vents before you install them. Once installed, you can apply any necessary touch-up paint/finish.
- Clean installation surface and back of vent of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the vent are completely dry before attempting installation.
- Measure and mark the location where the vent is going to be installed.

Important Safety Instructions

- Make sure to use the correct tools recommended.
- Wear safety goggles.
- Follow fixture, power tools, and paint manufacturers' instructions and users manuals.
- Use common sense and follow good construction practices.

Installation Process

1. Lay the vent face down on a soft surface that will not scratch/dent the vent detail.
2. Apply a 1/2" bead of adhesive caulk all the way around the back edge of the vent.
3. When pressing the vent up against the surface, some adhesive caulk will seep out. Smooth excess caulk around the vent with a finger or the putty knife and apply extra caulk that is needed to fill in any gaps.
4. Wipe off any excess adhesive caulk with a sponge or damp rag.
5. Non-corrosive fasteners can be used for additional support.



6. Fill any holes with caulk and smooth the surface with a finger or the putty knife. If any excess caulk is left, let it dry, and then lightly sand it down with extra fine sand paper.
7. Touch up the vent with any paint that is needed.