

Item # 303329581  
Model # HYLS-7208



## USE AND CARE GUIDE

### 72-INCH 8-DRAWER AND 1-DOOR STAINLESS STEEL MOBILE WORKBENCH

Questions, problems, missing parts?  
Before returning to the store, call  
Husky Customer Service  
8 a.m. – 7 p.m., EST, Monday-Friday  
9 a.m. – 6 p.m., EST, Saturday

1-888-HD-HUSKY

HUSKYTOOLS.COM



#### THANK YOU

*We appreciate the trust and confidence you have placed in Husky through the purchase of this workbench. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Husky!*

# Table of Contents


**Table of Contents** .....2  
**Safety Information** .....2  
    Warnings.....2  
**Warranty**.....3  
    1 YEAR LIMITED WARRANTY.....3  
    What is Covered .....3  
    What is Not Covered .....3  
**Pre-assembly** .....4  
    Planning Assembly.....4


    Tools Required ..... 4  
    Product Specifications..... 4  
    Hardware Included ..... 4  
    Package Contents ..... 5  
**Assembly**.....6  
**Operation**.....8  
**Care and Cleaning**.....9  
**Service Parts**.....10  
    Workbench ..... 10


# Safety Information


## WARNINGS


1. Do not overload the product.
2. Do not let children approach the product.
3. Do not open more than one drawer at a time.
4. To help prevent the product from tipping, load the product starting with the bottom drawers.
5. Lock all drawers and door before moving the product.
6. Make sure all drawers close tightly before locking/unlocking.
7. Do not step in any drawer/drawers.
8. Keep the locking casters’ brake set unless you are moving the product. This will help to prevent the product from rolling.
9. When moving this product, push it rather than pull it.
10. Do not modify the product in any way. Unauthorized modification may impair the function and/or safety of the product, and may affect the life of the product.

 **DANGER:** Read and understand all instructions. Failure to follow all instructions may result in injury and/or damage.

 **DANGER:** Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts, and never use this product with a damaged part.

 **WARNING:** The warnings, cautions, and instructions discussed in this manual cannot cover all possible conditions or situations that may occur.

 **WARNING:** Before using this product, carefully check that all parts are in good condition, and that the product will operate properly and perform its intended function.

 **CAUTION:** The user must always be aware of their environment and ensure that they use the product in a safe and responsible manner.

# Warranty

---

## 1 YEAR LIMITED WARRANTY

### WHAT IS COVERED

Manufacturer warrants to the original consumer purchaser (“Purchaser”) of the 72-inch 8-drawer and 1-door stainless steel mobile workbench (“Product”) that each Product shall be free from defects in workmanship and materials for a period of 1 year from the date of original purchase. The manufacturer obligation under this warranty shall be limited to repair or replacement of, or adequate compensation for the Product which shall not be greater than the amount of the purchase price of the Product, at the option of the manufacturer, during the warranty period. All replaced parts and Products become the property of the manufacturer and must be returned to the manufacturer.

This warranty excludes normal wear and tear of the Product and its parts or components, and damage arising from any of the following: negligent use or misuse of the Product, use contrary to this use and user guide, or alteration by anyone other than the manufacturer. The warranty period of 1 year shall not be extended or renewed by the repair or replacement of, or compensation for, the Product. Any warranty implied by applicable law is limited in duration to one year from the date of purchase and is subject to the same conditions and limitations as is provided for our express warranty.

Except as set forth herein, and to the extent applicable, there are no warranties on this Product either express or implied, and the manufacturer disclaims all warranties including, but not limited to, any implied warranties of merchantability, infringement or fitness for a particular purpose. No warranty or guarantee given by any person, firm, or corporation with respect to this product shall be binding on the manufacturer.

### WHAT IS NOT COVERED

The manufacturer (and its employees, officers, members, managers, affiliates and assigns) shall not be liable for any incidental, consequential, special, indirect, remote, special or punitive damages for breach of any warranty, express or implied, including, but not limited to, lost profits, lost savings, loss of anticipated benefits and attorneys’ fees, which arise out of the purchase, use or inability to use the Product, whether arising out of contract, negligence, strict tort, product liability, or any other legal theory on which a claim is based. As noted above, to the extent damages are allowed by our express warranty or by applicable law, those damages may not exceed the purchase price paid for the Product. Without limiting the foregoing Purchaser assumes all risk and liability for loss, damage or injury to Purchaser and Purchaser’s property and to others and their property arising out of the use, misuse, or inability to use this Product. This limited warranty shall not extend to anyone other than the original purchaser of this product, is nontransferable and states your exclusive remedy.


Some states do not allow the exclusion or limitation of incidental, consequential, special, or punitive damages, so the above limitation or exclusion may not apply to you. The above warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Contact the Customer Service Team at 1-888-HD-HUSKY or visit [www.HUSKYTOOLS.com](http://www.HUSKYTOOLS.com).

# Pre-assembly

## PLANNING ASSEMBLY

Unpack all items and compare them to the Hardware Included and Package Contents lists. Lay all parts on a flat non-abrasive surface such as cardboard or carpet. If any item appears damaged or is missing, do not assemble the product and contact customer service.


 **WARNING:** It is recommended that at least two people assemble this product.

## TOOLS REQUIRED





## PRODUCT SPECIFICATIONS

Maximum Capacity Per Drawer	75 lbs
Maximum Capacity Per Shelf	50 lbs
Maximum Total Capacity	1000 lbs

 **NOTE:** Begin product assembly close to the final intended location of your workbench. This product is heavy and may be difficult to move after assembly.

## HARDWARE INCLUDED


 **NOTE:** Hardware not shown to actual size.



Part	Description	Quantity
AA	Handle Bolt M6	6
BB	Caster Bolt M8	16
CC	Plugs	6
DD	Shelf Support	4
EE	Wrench	1

# Pre-assembly (continued)

## PACKAGE CONTENTS



Part	Description	Quantity
A	Workbench	1
B	Side Handle	1
C	Fixed Caster	2
D	Swivel Caster	2
E	Shelf	1
F	Liner	10
G	Key	4


# Assembly

## 1 Attaching the side handle



**NOTE:** The side handle could be installed on either the left or right side of the workbench as desired.

- Position the side handle (B) over pre-installed nuts on the desired side of the workbench (A).
- Insert the handle bolts (AA) through the holes on the side handle (B).
- Use a wrench (EE) or 10 mm wrench/socket (not included) to tighten the handle bolts (AA) to the workbench (A).
- Install the plugs (CC) over the pre-installed nuts on the opposite side of the side handle (B).



## 2 Attaching the casters



**WARNING:** At least two people are needed to lay down the workbench. Do not attempt this alone.

- Lay the workbench (A) on its backside.
- Position the swivel casters (D) on the side of the workbench (A) of your choice and align the holes to the pre-installed nuts on the underside of the workbench (A).
- Use the wrench (EE) to fully tighten the caster bolts (BB) to the workbench (A).
- Repeat these steps to install the fixed casters (C).




**NOTE:** Make sure to install both of the swivel casters (D) on the same side.



**NOTE:** For ease of use, place swivel casters (D) on the side you will regularly push or pull.



**NOTE:** If you plan to push the workbench against a wall, place swivel casters (D) on the front long side for ease of access.




## Assembly (continued)

### 3 Attaching shelf supports




**WARNING:** At least two people are needed to lift the workbench. Do not attempt this alone.

- Carefully lift the workbench upright.
- The shelf (E) is shipped upside down at the bottom inside the cabinet. Tilt the shelf (E) diagonally and remove it from the cabinet. Flip it over so the flat surface faces up.
- Determine which location the shelf is desired. Place the shelf supports (DD) by hooking them over the tabs. Make sure all four shelf supports (DD) are at the same level.




### 4 Installing the shelf

- Slide the shelf (E) in on top of all four shelf supports (DD).



### 5 Installing liners


- Place the matching liners (F) in each drawer and on each shelf.



# Operation


## 1 Removing the drawers

- Pull the drawer out so that it is almost fully extended.
- On the RIGHT-hand side, push the black release lever DOWN.
- On the LEFT-hand side, pull the black release lever UP.
- While holding the levers as instructed, pull the drawer forward until released from the slides attached to the workbench.



## 2 Replacing the drawers

- To replace the drawer, pull the slides out completely.
- Insert the brackets on each side of the drawer slides into the corresponding slots on the workbench slides, making sure they are properly positioned.
- Once the brackets are inserted into the slots, completely close the drawer to set all slides in their proper positions.



## 3 Locking and unlocking



**NOTE:** Drawer lock and cabinet lock use different keys. Match the code on the lock to the code on the key.

- To lock the unit, insert the key (G) into the lock cylinder and turn it 1/4-turn to the left. Then remove the key.
- To unlock the unit, insert the key (G) into the lock cylinder and turn it 1/4-turn to the right. Then remove the key.



**NOTE:** The drawers must be fully closed before locking or unlocking the unit.



## Care and Cleaning

---


- Avoid harsh, abrasive cleaners, and other corrosive chemicals.
- Do not use a scouring pad for cleaning.
- Keep dry and avoid damp environments.
- Use a quality stainless steel cleaner and follow instructions that come with the cleaner. Wipe ALONG the grain (NOT against).
- Wood top can be cleaned with a damp cloth and wiped dry immediately with a dry cloth. If needed, solvent-based wood furniture cleaner can be used.
- Clean up any spills immediately to prevent stains from forming on the wood top.

# Service Parts

## WORKBENCH



**NOTE:** Replacement keys may be ordered using the code shown on the face of the lock. The drawer and door lock may have different key codes.



Part	Description	Quantity
A	Shelf	1
B	Shelf Support	4
C	Handle Bolt	6
D	Side Handle	1
E	Door	1
F	Right Small Drawer	1
G	Right Medium Drawer	1
H	Right Large Drawer	1
I	Caster Bolt	16
J	Swivel Caster	2

Part	Description	Quantity
K	Wrench	1
L	Liner	10
M	Fixed Caster	2
N	Left Large Drawer	1
O	Left Medium Drawer	1
P	Left Small Drawer	2
Q	Full Length Drawer	1
R	Key	4
S	Lock	2
T	Wood Top	1



Questions, problems, missing parts? Before returning to the store,  
call Husky Customer Service  
8 a.m. – 7 p.m., EST, Monday-Friday, 9 a.m. – 6 p.m., EST, Saturday

**1-888-HD-HUSKY**

**HUSKYTOOLS.COM**

Retain this manual for future use.